

MHI

TECHNICAL MANUAL

**INVERTER WALL MOUNTED TYPE
RESIDENTIAL AIR-CONDITIONERS
(Split system, air to air heat pump type)**

SRK25ZMP-SJ

SRK35ZMP-SJ



MITSUBISHI HEAVY INDUSTRIES, LTD.


CONTENTS

1. SPECIFICATIONS	3
2. EXTERIOR DIMENSIONS	5
(1) Indoor units	5
(2) Outdoor units	6
(3) Wireless remote control	7
3. ELECTRICAL WIRING	8
(1) Indoor units	8
(2) Outdoor units	9
4. NOISE LEVEL	10
5. PIPING SYSTEM	12
6. RANGE OF USAGE & LIMITATIONS	13
7. CAPACITY TABLES	15
8. APPLICATION DATA	16
9. OUTLINE OF OPERATION CONTROL BY MICROCOMPUTER	24
(1) Operation control function by remote control	24
(2) Unit ON/OFF button	25
(3) Auto restart function	25
(4) Custom cord switching procedure	25
(5) High power operation	26
(6) Economy operation	26
(7) Flap control	26
(8) Timer operation	27
(9) Outline of heating operation	27
(10) Outline of cooling operation	29
(11) Outline of automatic operation	29
(12) Protection control function	30
(13) Outline of dry (dehumidifying) operation	36
10. MAINTENANCE DATA	37
(1) Cautions	37
(2) Items to check before troubleshooting	37
(3) Troubleshooting procedure (If the air conditioner does not run at all)	37
(4) Troubleshooting procedure (If the air conditioner runs)	38
(5) Self-diagnosis table	39
(6) Service mode (Trouble mode access function)	40

(7) Inspection procedures corresponding to detail of trouble	48
(8) Phenomenon observed after shortcircuit, wire breakage on sensor	52
(9) Checking the indoor electrical equipment	53
(10) How to make sure of wireless remote control	54
(11) Outdoor unit inspection points	55

■How to read the model name

Example:



1. SPECIFICATIONS

Model SRK25ZMP-SJ

Item	Model	SRK25ZMP-SJ			
		Indoor unit SRK25ZMP-SJ		Outdoor unit SRC25ZMP-SJ	
Power source		Single Phase, 220 - 240V, 50Hz			
Operation data	Nominal cooling capacity (range)	kW	2.5 (0.9 (Min.) - 2.8 (Max.))		
	Nominal heating capacity (range)	kW	2.8 (0.8 (Min.) - 3.9 (Max.))		
	Power consumption	Cooling	0.780 (0.25 - 1.01)		
		Heating	0.755 (0.20 - 1.43)		
	Max power consumption		1.65		
	Running current	Cooling	3.9 / 3.8 / 3.6 (220 / 230 / 240 V)		
		Heating	3.8 / 3.7 / 3.5 (220 / 230 / 240 V)		
	Inrush current, max current		3.9 / 3.8 / 3.6 (220 / 230 / 240 V) Max. 9		
	Power factor	Cooling	90		
		Heating	89		
EER	Cooling		3.21		
COP	Heating		3.71		
Sound power level	Cooling		59	60	
			58	59	
	Sound pressure level	Cooling	Hi: 45 Me: 34 Lo: 23	47	
		Heating	Hi: 43 Me: 34 Lo: 26	45	
	Silent mode sound pressure level		—	—	
Exterior dimensions (Height x Width x Depth)	mm	262 x 769 x 210	540 x 645(+57) x 275		
Exterior appearance (Munsell color)		Fine snow (8.0Y 9.3/0.1) near equivalent	Stucco white (4.2Y 7.5/1.1) near equivalent		
Net weight	kg	6.9	25		
Compressor type & Q'ty		—	RM-B5077MDE5(Rotary type) x 1		
Compressor motor (Starting method)	kW	—	0.75 (Inverter driven)		
Refrigerant oil (Amount, type)	ℓ	—	0.3 (DIAMOND FREEZE MA68)		
Refrigerant (Type, amount, pre-charge length)	kg	R410A 0.655 in outdoor unit (incl. the amount for the piping of 10m)			
Heat exchanger		Louver fins & inner grooved tubing	M fins & inner grooved tubing		
Refrigerant control		Capillary tubes + Electronic expansion valve			
Fan type & Q'ty		Tangential fan x 1	Propeller fan x 1		
Fan motor (Starting method)	W	30 x1 (Direct drive)	24 x1 (Direct drive)		
Air flow	Cooling	Hi: 10.1 Me: 7.3 Lo: 4.2	26.0		
	Heating	Hi: 9.5 Me: 7.3 Lo: 5.2	19.7		
Available external static pressure	Pa	0	0		
Outside air intake		Not possible	—		
Air filter, Quality / Quantity		Polypropylene net (washable)	—		
Shock & vibration absorber		Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)		
Electric heater		—	—		
Operation control	Remote control		Wireless remote control		
	Room temperature control		Microcomputer thermostat		
	Operation display		RUN: Green, TIMER: Yellow		
Safety equipments		Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Indoor fan motor error protection, Heating overload protection (High pressure control), Cooling overload protection			
Installation data	Refrigerant piping size (O.D)	mm	Liquid line : ϕ 6.35 (1/4") Gas line : ϕ 9.52 (3/8")		
	Connecting method		Flare connection	Flare connection	
	Attached length of piping	m	Liquid line : 0.39 / Gas line : 0.32	—	
	Insulation for piping		Necessary (Both sides), independent		
	Refrigerant line (one way) length	m	Max. 15		
	Vertical height diff. between O.U. and I.U.	m	Max. 10 (Outdoor unit is higher) / Max. 10 (Outdoor unit is lower)		
	Drain hose		Hose connectable (VP 16)	Holes ϕ 20 x 2 pcs	
Drain pump, max lift height	mm	—	—	—	
Recommended breaker size	A		16		
L.R.A. (Locked rotor ampere)	A	3.9 / 3.8 / 3.6 (220 / 230 / 240 V)			
Interconnecting wires	Size x Core number	1.5mm ² x 4 cores (Including earth cable) / Terminal block (Screw fixing type)			
IP number		IPX0	IPX4		
Standard accessories		Mounting kit			
Option parts		—			

Note (1) The data are measured at the following conditions.

The pipe length is 7.5m.

item	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
operation	Cooling	27°C	19°C	35°C	24°C
	Heating	20°C	—	7°C	6°C
					ISO5151-T1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.

(4) Select the breaker size according to the own national standard.

(5) The refrigerant quantity to be charged includes the refrigerant in 10 m connecting piping.

(purging is not required even for the short piping.)

If the piping length is longer, when it is 10 to 15 m, add 20 g refrigerant per meter.


Model SRK35ZMP-SJ

Item	Model	SRK35ZMP-SJ																							
		Indoor unit SRK35ZMP-SJ		Outdoor unit SRC35ZMP-SJ																					
Power source		Single Phase, 220 - 240V, 50Hz																							
Operation data	Nominal cooling capacity (range)	kW	3.2 (0.9 (Min.) - 3.5 (Max.))																						
	Nominal heating capacity (range)	kW	3.6 (0.9 (Min.) - 4.3 (Max.))																						
	Power consumption	Cooling	0.995 (0.23 - 1.32)																						
		Heating	0.995 (0.19 - 1.31)																						
	Max power consumption		1.65																						
	Running current	Cooling	4.9 / 4.7 / 4.5 (220 / 230 / 240 V)																						
		Heating	4.9 / 4.7 / 4.5 (220 / 230 / 240 V)																						
	Inrush current, max current		4.9 / 4.7 / 4.5 (220 / 230 / 240 V) Max. 9																						
	Power factor	Cooling	93																						
		Heating	93																						
Exterior dimensions (Height x Width x Depth)	mm	262 x 769 x 210			540 x 645(+57) x 275																				
Exterior appearance (Munsell color)		Fine snow (8.0Y 9.3/0.1) near equivalent		Stucco white (4.2Y 7.5/1.1) near equivalent																					
Net weight	kg	7.2			27																				
Compressor type & Q'ty		—			RM-B5077MDE5(Rotary type) x 1																				
Compressor motor (Starting method)	kW	—			0.90 (Inverter driven)																				
Refrigerant oil (Amount, type)	l	—			0.3 (DIAMOND FREEZE MA68)																				
Refrigerant (Type, amount, pre-charge length)	kg	R410A 0.81 in outdoor unit (incl. the amount for the piping of 15m)																							
Heat exchanger		Louver fins & inner grooved tubing		M fins & inner grooved tubing																					
Refrigerant control		Capillary tubes + Electronic expansion valve																							
Fan type & Q'ty		Tangential fan x 1		Propeller fan x 1																					
Fan motor (Starting method)	W	30 x1 (Direct drive)			24 x1 (Direct drive)																				
Air flow	Cooling Heating	m³/min	Hi: 9.5 Me: 6.8 Lo: 4.2	25.4																					
			Hi: 9.6 Me: 7.4 Lo: 5.5	20.5																					
Available external static pressure	Pa	0			0																				
Outside air intake		Not possible			—																				
Air filter, Quality / Quantity		Polypropylene net (washable)			—																				
Shock & vibration absorber		Rubber sleeve (for fan motor)			Rubber sleeve (for fan motor & compressor)																				
Electric heater		—			—																				
Operation control	Remote control	Wireless remote control																							
	Room temperature control	Microcomputer thermostat																							
	Operation display	RUN: Green, TIMER: Yellow																							
Safety equipments		Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Indoor fan motor error protection, Heating overload protection (High pressure control), Cooling overload protection																							
Installation data	Refrigerant piping size (O.D)	mm	Liquid line : ϕ 6.35 (1/4") Gas line : ϕ 9.52 (3/8")																						
	Connecting method		Flare connection		Flare connection																				
	Attached length of piping	m	Liquid line : 0.39 / Gas line : 0.32	—																					
	Insulation for piping		Necessary (Both sides), independent																						
	Refrigerant line (one way) length	m	Max. 15																						
	Vertical height diff. between O.U. and I.U.	m	Max. 10 (Outdoor unit is higher) / Max. 10 (Outdoor unit is lower)																						
	Drain hose		Hose connectable (VP 16)	Holes ϕ 20 x 2 pcs																					
Drain pump, max lift height	mm	—			—																				
Recommended breaker size	A	16																							
L.R.A. (Locked rotor ampere)	A	4.9 / 4.7 / 4.5 (220 / 230 / 240 V)																							
Interconnecting wires	Size x Core number	1.5mm² x 4 cores (Including earth cable) / Terminal block (Screw fixing type)																							
IP number		IPX0		IPX4																					
Standard accessories		Mounting kit																							
Option parts		—																							
Note (1) The data are measured at the following conditions. (2) This air-conditioner is manufactured and tested in conformity with the ISO. (3) Sound level indicates the value in an anechoic chamber. During operation these value are somewhat higher due to ambient conditions. (4) Select the breaker size according to the own national standard. (5) The refrigerant quantity to be charged includes the refrigerant in 15 m connecting piping. (purging is not required even for the short piping.)																									
<table border="1"> <thead> <tr> <th rowspan="2">item</th> <th colspan="2">Indoor air temperature</th> <th colspan="2">Outdoor air temperature</th> <th rowspan="2">Standards</th> </tr> <tr> <th>DB</th> <th>WB</th> <th>DB</th> <th>WB</th> </tr> </thead> <tbody> <tr> <td>Cooling</td> <td>27°C</td> <td>19°C</td> <td>35°C</td> <td>24°C</td> <td rowspan="2">ISO5151-T1</td> </tr> <tr> <td>Heating</td> <td>20°C</td> <td>—</td> <td>7°C</td> <td>6°C</td> </tr> </tbody> </table>					item	Indoor air temperature		Outdoor air temperature		Standards	DB	WB	DB	WB	Cooling	27°C	19°C	35°C	24°C	ISO5151-T1	Heating	20°C	—	7°C	6°C
item	Indoor air temperature		Outdoor air temperature			Standards																			
	DB	WB	DB	WB																					
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1																				
Heating	20°C	—	7°C	6°C																					

2. EXTERIOR DIMENSIONS

(1) Indoor units

Models SRK25ZMP-SJ, 35ZMP-SJ





(2) Outdoor units

Models SRC25ZMP-SJ, 35ZMP-SJ

Symbol	Content
A	Service valve connection (gas side)
B	Service valve connection (liquid side)
C	Pipe / cable draw-out hole
D	Drain discharge hole
E	Anchor bolt hole



- Notes**

 - (1) It must not be surrounded by walls on the four sides.
 - (2) The unit must be fixed with anchor bolts. An anchor bolt must not protrude more than 15mm.
 - (3) Where the unit is subject to strong winds, lay it in such a direction that the blower outlet faces perpendicularly to the dominant wind direction.
 - (4) Leave 1m or more space above the unit.
 - (5) A wall in front of the blower outlet must not exceed the units height.
 - (6) The model name label is attached on the right side of the unit.




Minimum installation space

Examples of installation Dimensions		I	II	III	IV
L1	Open	280	280	180	
L2	100	100	Open	Open	
L3	100	80	80	80	
L4	250	Open	250	Open	



(3) Wireless remote control

Unit: mm




3. ELECTRICAL WIRING

(1) Indoor units

Models SRK25ZMP-SJ, 35ZMP-SJ


Item	Description
CNE	Connector
CNF	
CNG	
CNM	
CNU	
FM	Fan motor
SM	Flap motor
HD	Humidity sensor
Th _i	Room temp. sensor
Th ₂	Heat exch. sensor
DS	Diode stack
F	Fuse
TB	Terminal block
V _a	Varistor

Mark	Color
BK	Black
BL	Blue
RD	Red
WH	White
Y	Yellow
Y/G	Yellow/Green




(2) Outdoor units

Models SRC25ZMP-SJ, 35ZMP-SJ



Power cable: indoor-outdoor connecting wires

Model	MAX running current (A)	Power cable size (mm²)	Power cable length (m)	indoor-outdoor wire size x number (mm²)	Earth wire size (mm²)
25	9	2.0	32	1.5mm² x 4	1.5
35					



Item	Description	Mark	Color
CM	Compressor motor	BK	Black
CN20S	Connector	OR	Orange
CNEEV		RD	Red
CNFAN		WH	White
CNTH		Y	Yellow
EEV	Electric expansion valve (coil)	Y/G	Yellow/Green
FMo	Fan motor		
L	Reactor		
TB	Terminal block		
TH1	Heat exchanger sensor (outdoor unit)		
TH2	Outdoor air temp. sensor		
TH3	Discharge pipe temp. sensor		
20S	Solenoid coil for 4 way valve		

*The specifications shown in the above table are for units without heaters. For units with heaters, refer to the installation instructions or the construction instructions of the indoor unit.

*Switchgear of Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.

*The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.

4. NOISE LEVEL

Model SRK25ZMP-SJ

(Indoor Unit)


Model	SRK25ZMP-SJ	
Noise Level	Cooling	45 dB(A)
	Heating	43 dB(A)

Condition ISO-T1,JIS C 9612

●Mike position



x Cooling ○ — Heating




(Outdoor Unit)

Model	SRC25ZMP-SJ	
Noise Level	Cooling	47 dB(A)
	Heating	45 dB(A)

●Mike position: at highest noise level in position as mentioned below
Distance from front side 1m

x Cooling ○ — Heating




Model SRK35ZMP-SJ

(Indoor Unit)


Model	SRK35ZMP-SJ	
Noise Level	Cooling	Heating
	47 dB(A)	44 dB(A)

Condition ISO-T1,JIS C 9612

● Mike position



x Cooling ○ — Heating




(Outdoor Unit)

Model	SRC35ZMP-SJ	
Noise Level	Cooling	Heating
	49 dB(A)	48 dB(A)


● Mike position: at highest noise level in position as mentioned below
Distance from front side 1m

x Cooling ○ — Heating



5. PIPING SYSTEM

Models SRK25ZMP-SJ, 35ZMP-SJ



6. RANGE OF USAGE & LIMITATIONS


Models	SRK25ZMP-SJ, 35ZMP-SJ	
Item		
Indoor return air temperature (Upper, lower limits)	Cooling operation : Approximately 18 to 32°C D.B. Heating operation : Approximately 15 to 30°C D.B. (Refer to the selection chart)	
Outdoor air temperature (Upper, lower limits)	Cooling operation : Approximately -15 to 46°C D.B. Heating operation : Approximately -15 to 24°C D.B. (Refer to the selection chart)	
Refrigerant line (one way) length	Max. 15m	Max. 25m
Vertical height difference between outdoor unit and indoor unit	Max. 10m (Outdoor unit is higher) Max. 10m (Outdoor unit is lower)	Max. 15m (Outdoor unit is higher) Max. 15m (Outdoor unit is lower)
Power source voltage	Rating ±10%	
Voltage at starting	Min. 85% of rating	
Frequency of ON-OFF cycle	Max. 4 times/h (Inching prevention 10 minutes)	
ON and OFF interval	Min. 3 minutes	

Selection chart

Correct the cooling and heating capacity in accordance with the conditions as follows. The net cooling and heating capacity can be obtained in the following way.

Net capacity = Capacity shown on specification × Correction factors as follows.

(1) Coefficient of cooling and heating capacity in relation to temperatures



(2) Correction of cooling and heating capacity in relation to one way length of refrigerant piping

It is necessary to correct the cooling and heating capacity in relation to the one way piping length between the indoor and outdoor units.

Piping length [m]	7	10	15	20	25	30
Cooling	1.0	0.99	0.975	0.965	0.95	0.935
Heating	1.0	1.0	1.0	1.0	1.0	1.0

(3) Correction relative to frosting on outdoor heat exchanger during heating

In addition to the foregoing corrections (1), (2) the heating capacity needs to be adjusted also with respect to the frosting on the outdoor heat exchanger.

Air inlet temperature of outdoor unit in °CWB	-15	-10	-9	-7	-5	-3	-1	1	3	5 or more
Adjustment coefficient	0.95	0.95	0.94	0.93	0.91	0.88	0.86	0.87	0.92	1.00

How to obtain the cooling and heating capacity

Example : The net cooling capacity of the model SRK35ZMP-SJ with the piping length of 15m, indoor wet-bulb temperature at 19.0°C and outdoor dry-bulb temperature 35°C is Net cooling capacity =

$$\frac{3.2 \times 0.975 \times 1.0}{\text{SRK35ZMP-SJ} \quad \text{Length 15m}} \doteq 3.1 \text{kW}$$

Factor by air temperatures

7. CAPACITY TABLES

Model SRK25ZMP-SJ

Air flow (m³/min)	Outdoor air temp. °CWB	Cooling Mode										(kW)			
		Indoor air temp													
		21°CDB	23°CDB	26°CDB	27°CDB	28°CDB	31°CDB	33°CDB	TC	SHC	TC	SHC			
Hi 10.1	10	2.82	2.36	2.95	2.32	3.06	2.42	3.11	2.39	3.16	2.36	3.26	2.46	3.34	2.39
	12	2.77	2.34	2.90	2.30	3.01	2.40	3.07	2.37	3.12	2.35	3.22	2.45	3.31	2.38
	14	2.71	2.31	2.85	2.27	2.97	2.39	3.03	2.36	3.08	2.33	3.18	2.43	3.28	2.37
	16	2.66	2.28	2.80	2.25	2.92	2.37	2.98	2.35	3.04	2.32	3.15	2.42	3.24	2.36
	18	2.60	2.26	2.74	2.23	2.88	2.35	2.94	2.33	2.99	2.31	3.11	2.41	3.20	2.35
	20	2.55	2.23	2.68	2.21	2.83	2.33	2.89	2.31	2.95	2.29	3.07	2.39	3.17	2.34
	22	2.49	2.20	2.63	2.18	2.78	2.31	2.84	2.29	2.90	2.27	3.02	2.38	3.13	2.32
	24	2.43	2.18	2.57	2.15	2.72	2.29	2.80	2.27	2.85	2.25	2.98	2.36	3.08	2.31
	26	2.37	2.14	2.51	2.13	2.67	2.27	2.74	2.25	2.80	2.23	2.93	2.35	3.04	2.29
	28	2.31	2.12	2.44	2.10	2.61	2.24	2.69	2.23	2.75	2.21	2.89	2.33	3.00	2.28
	30	2.24	2.09	2.38	2.07	2.56	2.22	2.64	2.21	2.70	2.19	2.84	2.31	2.95	2.27
	32	2.18	2.06	2.31	2.04	2.50	2.20	2.58	2.19	2.64	2.17	2.79	2.30	2.90	2.25
	34	2.11	2.03	2.25	2.01	2.44	2.18	2.53	2.17	2.59	2.15	2.74	2.28	2.85	2.24
	35	2.08	2.01	2.21	2.00	2.41	2.16	2.50	2.16	2.56	2.14	2.71	2.27	2.83	2.23
	36	2.04	1.99	2.18	1.98	2.38	2.15	2.47	2.14	2.53	2.13	2.69	2.26	2.80	2.22
	38	1.97	1.97	2.11	1.95	2.32	2.12	2.41	2.12	2.47	2.11	2.63	2.24	2.75	2.20
	39	1.94	1.94	2.07	1.94	2.28	2.11	2.38	2.11	2.44	2.10	2.61	2.23	2.72	2.20

Model SRK35ZMP-SJ

Air flow (m³/min)	Outdoor air temp. °CWB	Cooling Mode										(kW)			
		Indoor air temp													
		21°CDB	23°CDB	26°CDB	27°CDB	28°CDB	31°CDB	33°CDB	TC	SHC	TC	SHC			
Hi 9.5	10	3.61	2.75	3.77	2.70	3.91	2.80	3.98	2.76	4.05	2.72	4.17	2.79	4.28	2.70
	12	3.54	2.72	3.71	2.67	3.86	2.77	3.93	2.73	4.00	2.70	4.12	2.77	4.24	2.68
	14	3.47	2.69	3.65	2.64	3.80	2.74	3.87	2.71	3.94	2.67	4.08	2.75	4.19	2.67
	16	3.40	2.65	3.58	2.61	3.74	2.72	3.82	2.68	3.89	2.64	4.03	2.74	4.15	2.65
	18	3.33	2.61	3.51	2.57	3.68	2.68	3.76	2.66	3.83	2.62	3.98	2.71	4.10	2.64
	20	3.26	2.58	3.44	2.54	3.62	2.66	3.70	2.63	3.78	2.60	3.92	2.69	4.05	2.61
	22	3.19	2.54	3.36	2.51	3.55	2.63	3.64	2.61	3.71	2.58	3.87	2.68	4.00	2.59
	24	3.11	2.50	3.29	2.47	3.49	2.60	3.58	2.58	3.65	2.56	3.81	2.64	3.95	2.58
	26	3.03	2.46	3.21	2.43	3.42	2.57	3.51	2.55	3.59	2.53	3.76	2.62	3.89	2.56
	28	2.95	2.42	3.13	2.39	3.35	2.54	3.45	2.53	3.52	2.50	3.70	2.61	3.84	2.55
	30	2.87	2.38	3.05	2.35	3.27	2.51	3.38	2.50	3.45	2.47	3.64	2.59	3.78	2.52
	32	2.79	2.34	2.96	2.32	3.20	2.48	3.31	2.47	3.38	2.45	3.57	2.56	3.72	2.51
	34	2.70	2.30	2.88	2.28	3.12	2.45	3.24	2.44	3.31	2.42	3.51	2.54	3.65	2.48
	35	2.66	2.27	2.83	2.26	3.08	2.43	3.20	2.43	3.28	2.40	3.47	2.52	3.62	2.47
	36	2.61	2.25	2.79	2.24	3.04	2.41	3.16	2.41	3.24	2.39	3.44	2.51	3.59	2.46
	38	2.52	2.21	2.70	2.20	2.96	2.38	3.09	2.38	3.16	2.36	3.37	2.49	3.52	2.44
	39	2.48	2.19	2.65	2.18	2.92	2.36	3.05	2.36	3.12	2.34	3.34	2.48	3.49	2.43

Air flow (m³/min)	Outdoor air temp. °CWB	Heating Mode(HC)										(kW)	
		Outdoor air temp.		Indoor air temp									
				16°CDB	18°CDB	20°CDB	22°CDB	24°CDB	TC	SHC	TC	SHC	
Hi 9.5	-15°CWB	1.72	1.69	1.65	1.61	1.58							
	-10°CWB	1.95	1.91	1.89	1.84	1.80							
	-5°CWB	2.11	2.08	2.04	2.02	1.98							
	0°CWB	2.21	2.18	2.14	2.12	2.09							
	5°CWB	2.82	2.79	2.77	2.72	2.68							
	6°CWB	2.87	2.83	2.80	2.76	2.73							
	10°CWB	3.04	3.02	3.00	2.96	2.93							
	15°CWB	3.31	3.28	3.26	3.23	3.20							
	20°CWB	3.56	3.53	3.52	3.48	3.45							

Air flow (m³/min)	Outdoor air temp. °CWB	Heating Mode(HC)										(kW)	
		Outdoor air temp.		Indoor air temp									
				16°CDB	18°CDB	20°CDB	22°CDB	24°CDB	TC	SHC	TC	SHC	
Hi 9.6	15°CWB	2.21	2.17	2.12	2.07	2.03							
	-10°CWB	2.51	2.46	2.43	2.37	2.32							
	-5°CWB	2.71	2.68	2.62	2.59	2.55							
	0°CWB	2.85	2.80	2.76	2.72	2.68							
	5°CWB	3.63	3.58	3.56	3.49	3.44							
	6°CWB	3.68	3.64	3.60	3.55	3.51							
	10°CWB	3.91	3.88	3.85	3.80	3.76							
	15°CWB	4.26	4.22	4.19	4.15	4.11							
	20°CWB	4.58	4.54	4.52	4.47	4.43							

Note(1) These data show average statuses.
Depending on the system control, there may be ranges where the operation is not conducted continuously.

(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length : 7m
Level difference of Zero.

(3) Symbols are as follows.

TC : Total cooling capacity (kW)

SHC : Sensible heat capacity (kW)

HC : Heating capacity (kW)

8. APPLICATION DATA

Models SRK25ZMP-SJ, 35ZMP-SJ

- When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, power supply voltage and etc.) and installation spaces.

SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, **⚠ WARNING** and **⚠ CAUTION**.
- ⚠ WARNING :** Wrong installation might cause serious consequences such as injuries or death.
- ⚠ CAUTION :** Wrong installation might cause serious consequences depending on circumstances.
- Both mentions the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.
- Keep the installation manual together with owner's manual at a place where any user can read at any time.

⚠ WARNING

! Installation must be carried out by the qualified installer.

If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except them by qualified installer.

! Install the system in full accordance with the installation manual.

Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.

! Be sure to use only for household and residence.

If this appliance is installed in interior environment such as machine shop and etc., it can cause malfunction.

! Use the original accessories and the specified components for installation.

If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.

! Install the unit in a location with good support.

Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.

! Ensure the unit is stable when installed, so that it can withstand earthquakes and strong winds.

Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.

! Ventilate the working area well in the event of refrigerant leakage during installation.

If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.

! When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with IS 05149).

If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.

! Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulphide gas can occur.

Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.

! Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.

If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too

RYD012A230

**WALL TYPE AIR CONDITIONER
R410A REFRIGERANT USED**

- Moreover if necessary, ask to hand them to a new user.
- For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, gloves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.

- The meanings of "Marks" used here are shown as follows:
- Never do it under any circumstances.
- Always do it according to the instruction.

! Installation must be carried out by the qualified installer.	! After completed installation, check that no refrigerant leaks from the system.	! When plugging this appliance, a plug conforming to the norm IEC60884-1 must be used.
	• If refrigerant leaks into the room and comes into contact with an oven or other hot surface, poisonous gas is produced.	• Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks.
	• Using existing parts (for R22 or R407C) can cause heat production and serious accidents due to burst of the refrigerant circuit.	Loose connections or cable mountings can cause anomalous heat production or fire.
	• Tighten the flare nut by torque wrench with specified method.	• Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.
	• If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.	Incorrect installation may result in overheating and fire.
	• Do not open the operation valves for liquid line and gas line until completed refrigerant piping work, air tightness test and evacuation.	• Be sure to fix up the service panels.
	• If the compressor is operated in state of opening operation valves before completed connection of refrigerant piping work, air can be sucked into refrigerant circuit, which can cause burst or personal injury due to anomalous high pressure in the refrigerant.	incorrect fixing can cause electric shocks or due to infusion of dust or water.
	• The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.	• Be sure to switch off the power supply in the event of installation, inspection or servicing.
	Power supply with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.	If the power supply is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.
	• Be sure to shut off the power before starting electrical work.	• Stop the compressor before removing the pipe after shutting the service valve on pump down work.
	Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.	If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and could cause explosion and injuries due to abnormal high pressure in the cooling cycle.
	• Be sure to use the cables conforming to safety standard and cable ampacity for power distribution work.	• Only use prescribed option parts. The installation must be carried out by the qualified installer.
	Unconformable cables can cause electric leak, anomalous heat production or fire.	If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.
	• This appliance must be connected to main power supply by means of a circuit breaker or switch (fuse: 16A) with a contact separation of at least 3mm.	• Be sure to wear protective goggles and gloves while at work.
	high, which can cause burst and personal injury.	• Earth leakage breaker must be installed.
	• Do not process, splice the power cord, or share a socket with other power plugs.	If the earth leakage breaker is not installed, it can cause electric shocks.
	This may cause fire or electric shock due to detecting contact, defecting insulation and over-current etc.	• Do not vent R410A into the atmosphere. R410A is a fluorinated greenhouse gas, covered by the Kyoto Protocol with Global Warming Potential (GWP)=1975.
	• Do not bundle, winding or processing for the power cord. Or, do not deform the power plug due to treat it.	Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrainment, burn or electric shocks.
	This may cause fire or heating.	• Do not perform any change of protective device itself or its setup condition.
		The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.

⚠ CAUTION


<p>!</p> <ul style="list-style-type: none"> • Carry out the electrical work for ground lead with care. Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting. • Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnects all poles under over current. Using the incorrect one could cause the system failure and fire. • Install isolator or disconnect switch on the power supply wiring in accordance with the local codes and regulations. The isolator should be locked in OFF state in accordance with EN60204-1. • Be sure to install indoor unit properly according to the instruction manual in order to run off the trainees smoothly. Improper installation of indoor unit can cause dropping water into the room and damaging personal property. • Install the drainage pipe to turn off drainage securely according to the installation manual. Incorrect installation of the drainage pipe can cause dropping water into the room and damaging personal property. • Be sure to install the drainage pipe with descending slope of 1/100 or more, and not to make trans and air-bleedings. Check if the drainage runs off securely during commissioning and ensure the space for the drainage pipe to turn off. • Do not install the unit in the locations listed below. <ul style="list-style-type: none"> • Locations where carbon fiber, metal powder or any powder is floating. • Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkali can occur. • Vehicles and ships. • Locations where cosmetic or special sprays are often used. • Locations with direct exposure of oil mist and steam such as kitchen and machine plant. • Locations where any machines which generate high frequency harmonics are used. • Locations with salty atmospheres such as coastlines. • Locations with heavy snow (if installed, be sure to provide base flame and snow hood mentioned in the manual). • Locations where the unit is exposed to chimney smoke. • Locations at a high altitude (more than 1000m high). • Locations with ammonia atmospheres. • Locations where heat radiation from other heat source can affect the unit. • Locations without good air circulation. • Locations with any obstacles which can prevent inlet and outlet air of the unit. • Locations where short circuit of air can occur (in case of multiple units installation). • Locations where strong air blows against the air outlet of outdoor unit. • Locations where something located above the unit could fall. • It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire. • Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation). <ul style="list-style-type: none"> • Locations with any obstacles which can prevent inlet and outlet air of the unit. • Locations where vibration can be amplified due to insufficient strength of structure. • Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam in case of the infrared specification unit. • Locations where something located above the unit could fall. • Locations where drainage cannot run off safely. 	<p>!</p> <ul style="list-style-type: none"> • After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from all metal parts should be secured. • Secure a space for installation, inspection and maintenance specified in the manual. Insufficient space can result in accident such as personal injury due to falling from the installation place. • Take care when carrying the unit by hand. If the unit weighs more than 20kg, it must be carried by two or more persons. Do not carry by the plastic straps, always use the carry handle when carrying the unit by hand. Use gloves to minimize the risk of cuts by the aluminum fins. • Dispose of any packing materials correctly. Any remaining packing materials can cause personal injury as it contains nails and wood. And to avoid danger of suffocation, be sure to keep the plastic wrapper away from children and to dispose after read it up. • For installation work, be careful not to get injured with the heat exchanger, It can affect performance or function and etc. • Do not place any variables which will be damaged by getting wet under the indoor unit. When the relative humidity is higher than 80% or drainage pipe is clogged, condensation or drainage water can drop and it can cause the damage to variables. • Do not install the remote control at the direct sunlight. It can cause malfunction or deformation of the remote control. • Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art. It can cause the damage of the items. • Do not install the outdoor unit in a location where insects and small animals can inhabit. Insects and small animals can enter the electric parts and cause damage or fire. Instruct the user to keep the surroundings clean. • Do not use the base flange for outdoor unit which is corroded or damaged due to long periods of operation. Using an old and damage base flange can cause the unit falling down and cause personal injury. • Do not use any materials other than a use with the correct rating in the location where fuses are to be used. Connecting the circuit with copper wire or other metal thread can cause unit failure and fire. • Do not touch any buttons with wet hands. It can cause electric shocks. • Do not touch any refrigerant pipes with your hands when the system is in operation. During as the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury. • Do not touch the suction or aluminum fin on the outdoor unit. This may cause injury. • Do not put anything on the outdoor unit and operating unit. This may cause damage the objects or injury due to falling to the object. • Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art. • Do not clean up the unit with water. 	<p>!</p> <ul style="list-style-type: none"> • piping flare portion or screws etc. Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them. • Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling floor, furniture and any other valuables. • When perform the air conditioner operation (cooling or drying operation) in which ventilator is installed in the room. In this case, using the air conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (for example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc. • Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents. 	<p>!</p> <ul style="list-style-type: none"> • Do not place any variables which will be damaged by getting wet under the indoor unit. When the relative humidity is higher than 80% or drainage pipe is clogged, condensation or drainage water can drop and it can cause the damage to variables. • Do not install the remote control at the direct sunlight. It can cause malfunction or deformation of the remote control. • Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art. It can cause the damage of the items. • Do not install the outdoor unit in a location where insects and small animals can inhabit. Insects and small animals can enter the electric parts and cause damage or fire. Instruct the user to keep the surroundings clean. • Do not use the base flange for outdoor unit which is corroded or damaged due to long periods of operation. Using an old and damage base flange can cause the unit falling down and cause personal injury. • Do not use any materials other than a use with the correct rating in the location where fuses are to be used. Connecting the circuit with copper wire or other metal thread can cause unit failure and fire. • Do not touch any buttons with wet hands. It can cause electric shocks. • Do not touch any refrigerant pipes with your hands when the system is in operation. During as the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury. • Do not touch the suction or aluminum fin on the outdoor unit. This may cause injury. • Do not put anything on the outdoor unit and operating unit. This may cause damage the objects or injury due to falling to the object. • Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art. • Do not clean up the unit with water. 																																																																								
Necessary tools for the installation work																																																																											
<p>Standard accessories (Installation kit)</p> <table border="1"> <thead> <tr> <th>Accessories for indoor unit</th> <th>Qty</th> </tr> </thead> <tbody> <tr> <td>① Installation board</td> <td>1</td> </tr> <tr> <td>② Attached to the rear of the indoor unit</td> <td>1</td> </tr> <tr> <td>③ Wireless remote control</td> <td>1</td> </tr> <tr> <td>④ Remote control holder</td> <td>1</td> </tr> <tr> <td>⑤ Grommet</td> <td>1</td> </tr> <tr> <td>⑥ Drain elbow (Heat pump type only)</td> <td>1</td> </tr> <tr> <td>⑦ Grommet</td> <td>1</td> </tr> <tr> <td>⑧ Trapping screws</td> <td>5</td> </tr> <tr> <td>⑨ Installation board 64 X 25mm</td> <td>5</td> </tr> </tbody> </table>	Accessories for indoor unit	Qty	① Installation board	1	② Attached to the rear of the indoor unit	1	③ Wireless remote control	1	④ Remote control holder	1	⑤ Grommet	1	⑥ Drain elbow (Heat pump type only)	1	⑦ Grommet	1	⑧ Trapping screws	5	⑨ Installation board 64 X 25mm	5	<p>⑩ Vacuum pump</p> <table border="1"> <thead> <tr> <th>Option parts</th> <th>Qty</th> </tr> </thead> <tbody> <tr> <td>⑩ Sealing plate</td> <td>2</td> </tr> <tr> <td>⑪ Sleeve</td> <td>2</td> </tr> <tr> <td>⑫ Inclination plate</td> <td>1</td> </tr> <tr> <td>⑬ Putty</td> <td>1</td> </tr> <tr> <td>⑭ Drain hose (extension hose)</td> <td>1</td> </tr> <tr> <td>⑮ Piping cover</td> <td>1</td> </tr> <tr> <td>⑯ (for insulation of connection piping)</td> <td>1</td> </tr> </tbody> </table>	Option parts	Qty	⑩ Sealing plate	2	⑪ Sleeve	2	⑫ Inclination plate	1	⑬ Putty	1	⑭ Drain hose (extension hose)	1	⑮ Piping cover	1	⑯ (for insulation of connection piping)	1	<p>⑪ Vacuum pump adapter (Anti-reverse flow type)</p> <table border="1"> <thead> <tr> <th>Accessories for outdoor unit</th> <th>Qty</th> </tr> </thead> <tbody> <tr> <td>⑫ Knife</td> <td>2</td> </tr> <tr> <td>⑬ Saw</td> <td>3</td> </tr> <tr> <td>⑭ Tape measure</td> <td>4</td> </tr> <tr> <td>⑮ Hammer</td> <td>1</td> </tr> <tr> <td>⑯ Flaring tool set</td> <td>1</td> </tr> <tr> <td>⑰ Gauge manifold</td> <td>1</td> </tr> <tr> <td>⑱ Charge hose (Designed specifically for R410A)</td> <td>1</td> </tr> <tr> <td>⑲ Flaring tool set (Designed specifically for R410A)</td> <td>1</td> </tr> <tr> <td>⑳ Gauge manifold (Designed specifically for R410A)</td> <td>1</td> </tr> <tr> <td>㉑ Charge hose (Designed specifically for R410A)</td> <td>1</td> </tr> <tr> <td>㉒ Flaring tool set (Designed specifically for R410A)</td> <td>1</td> </tr> <tr> <td>㉓ Gauge manifold (Designed specifically for R410A)</td> <td>1</td> </tr> <tr> <td>㉔ Gas leak detector</td> <td>1</td> </tr> <tr> <td>㉕ Gauge for protection adjustment (Used when</td> <td>1</td> </tr> <tr> <td>㉖ Hole core drill (65mm in diameter)</td> <td>8</td> </tr> <tr> <td>㉗ Wrench key (Hexagon) (4mm/m)</td> <td>9</td> </tr> <tr> <td>㉘ Pipe bender</td> <td>17</td> </tr> </tbody> </table>	Accessories for outdoor unit	Qty	⑫ Knife	2	⑬ Saw	3	⑭ Tape measure	4	⑮ Hammer	1	⑯ Flaring tool set	1	⑰ Gauge manifold	1	⑱ Charge hose (Designed specifically for R410A)	1	⑲ Flaring tool set (Designed specifically for R410A)	1	⑳ Gauge manifold (Designed specifically for R410A)	1	㉑ Charge hose (Designed specifically for R410A)	1	㉒ Flaring tool set (Designed specifically for R410A)	1	㉓ Gauge manifold (Designed specifically for R410A)	1	㉔ Gas leak detector	1	㉕ Gauge for protection adjustment (Used when	1	㉖ Hole core drill (65mm in diameter)	8	㉗ Wrench key (Hexagon) (4mm/m)	9	㉘ Pipe bender	17	<p>⑫ Plus headed driver</p> <p>⑬ Gauge manifold</p> <p>⑭ Gauge manifold</p> <p>㉑ Charge hose (Designed specifically for R410A)</p> <p>㉒ Flaring tool set (Designed specifically for R410A)</p> <p>㉓ Gauge manifold (Designed specifically for R410A)</p> <p>㉔ Charge hose (Designed specifically for R410A)</p> <p>㉕ Flaring tool set (Designed specifically for R410A)</p> <p>㉖ Gauge for protection adjustment (Used when</p> <p>㉗ Hole core drill (65mm in diameter)</p> <p>㉘ Wrench key (Hexagon) (4mm/m)</p> <p>㉙ Pipe bender</p>
Accessories for indoor unit	Qty																																																																										
① Installation board	1																																																																										
② Attached to the rear of the indoor unit	1																																																																										
③ Wireless remote control	1																																																																										
④ Remote control holder	1																																																																										
⑤ Grommet	1																																																																										
⑥ Drain elbow (Heat pump type only)	1																																																																										
⑦ Grommet	1																																																																										
⑧ Trapping screws	5																																																																										
⑨ Installation board 64 X 25mm	5																																																																										
Option parts	Qty																																																																										
⑩ Sealing plate	2																																																																										
⑪ Sleeve	2																																																																										
⑫ Inclination plate	1																																																																										
⑬ Putty	1																																																																										
⑭ Drain hose (extension hose)	1																																																																										
⑮ Piping cover	1																																																																										
⑯ (for insulation of connection piping)	1																																																																										
Accessories for outdoor unit	Qty																																																																										
⑫ Knife	2																																																																										
⑬ Saw	3																																																																										
⑭ Tape measure	4																																																																										
⑮ Hammer	1																																																																										
⑯ Flaring tool set	1																																																																										
⑰ Gauge manifold	1																																																																										
⑱ Charge hose (Designed specifically for R410A)	1																																																																										
⑲ Flaring tool set (Designed specifically for R410A)	1																																																																										
⑳ Gauge manifold (Designed specifically for R410A)	1																																																																										
㉑ Charge hose (Designed specifically for R410A)	1																																																																										
㉒ Flaring tool set (Designed specifically for R410A)	1																																																																										
㉓ Gauge manifold (Designed specifically for R410A)	1																																																																										
㉔ Gas leak detector	1																																																																										
㉕ Gauge for protection adjustment (Used when	1																																																																										
㉖ Hole core drill (65mm in diameter)	8																																																																										
㉗ Wrench key (Hexagon) (4mm/m)	9																																																																										
㉘ Pipe bender	17																																																																										
Check before installation work																																																																											
<ul style="list-style-type: none"> • Model name and power source • Refrigerant piping length • Piping, wiring and miscellaneous small parts 																																																																											

SELECTION OF INSTALLATION LOCATION

(Install at location that meets the following conditions, after getting approval from the customer)

Indoor unit

- Where there is no obstructions to the air flow and where the cooled and heated air can be evenly distributed.
- A solid place where the unit or the wall will not vibrate.
- A place where there will be enough space for servicing. (Where space mentioned right can be secured)
- Where wiring and the piping work will be easy to conduct.
- The place where receiving part is not exposed to the direct rays of the sun or the strong rays of the street lighting.
- A place where it can be easily drained.
- A place separated at least 1m away from the TV or the radio. (To prevent interference to images and sounds.)
- Places where this unit is not affected by the high frequency equipment or electric equipment.
- Avoid installing this unit in place where there is much oil mist.
- Places where there is no electric equipment or household under the installing unit.




Wireless remote control

- A place where the air conditioner can be received the signal surely during operating the wireless remote control.
- Places where there is no affected by the TV and radio etc.
- Do not place where exposed to direct sunlight or near heat devices such as a stove.

Outdoor unit

- Where air is not trapped.
- Where the installation fittings can be firmly installed.
- Where wind does not hinder the intake and outlet pipes.
- Out of the heat range of other heat sources.
- A place where stringent regulation of electric noises is applicable.
- Where it is safe for the drain water to be discharged.
- Where noise and hot air will not bother neighboring residents.
- Where snow will not accumulate.
- Where strong winds will not blow against the outlet pipe.
- When the unit is installed, the space of the following dimension and above shall be secured.
(In case the barrier is 1.2m or above in height, or is overhead, the sufficient space between the unit and wall shall be secured.)

The height of a wall is 1200mm or less.



Size	Example Installation				(mm)
	I	II	III	IV	
L1	Open	280	280	180	
L2	100	100	Open	Open	
L3	100	80	80	80	
L4	250	Open	250	Open	

Limitation of the piping length


Model	SRK25, DXK09		SRK45, DXK15	
	Total one way length	Vertical height difference	MAX. 15m	MAX. 25m
	MAX. 15m	MAX. 10m	MAX. 10m	MAX. 15m
Additional refrigerant	Less than 10m : Not required More than 10m : 20g/m		Not required	Less than 15m : Not required More than 15m : 20g/m

HOW TO RELOCATE OR DISPOSE OF THE UNIT

- In order to protect the environment, be sure to pump down (recovery of refrigerant).
- Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit when the pipes are removed from the unit.


<How to pump down>

- ① Connect charge hose to check joint.
- ② Liquid side : Close the liquid valve with hexagon wrench key.
Gas side : Fully open the gas valve.
Carry out cooling operation. (If indoor temperature is low, operate forced cooling operation.)
- ③ After low pressure gauge become 0.01MPa, stop cooling operation and close the gas valve.



Mounting method of battery

- Uncover the wireless remote control, and mount the batteries (R03 (AAA, Micro), ×2 pieces) in the body regularly.
(Fit the poles with the indication marks, + & - without fail)




INSTALLATION OF WIRELESS REMOTE CONTROL

Fixing to pillar or wall

- Conventionally, operate the wireless remote control by holding in your hand.
- Avoid installing it on a clay wall etc.

CAUTION

- Do not use new and old batteries together.




EARTHING WORK

- Earth work shall be carried out without fail in order to prevent electric shock and noise generation.
- The connection of the earth cable to the following substances causes dangerous failures, therefore it shall never be done.
City water pipe, Town gas pipe, TV antenna, lightning conductor, telephone line, etc.

How to remove and install the front panel

- Removing
 - ① Remove the 2 set screws.
 - ② Remove the 3 latches in the upper section. And take off the front panel.
- Installing
 - ① Cover the body with the front panel. And lock the latches (on the base).
 - ② Tighten the 2 set screws.
 - ③ Carry out in the above order.




INSTALLATION OF INDOOR UNIT

Installation of Installation board

Fixing of installation board


Look for the inside wall structures (intermediate support or pillar and firmly install the unit after level surface has been checked.)

- Adjustment of the installation board in the horizontal direction is to be conducted with four screws in a temporary tightened state.
- Adjust so the board will be level by turning the board with the standard hole as the center.



Drilling of holes and fixture of sleeve (Option parts)

When drilling the wall that contains a metal lath, wire lath or metal plate, be sure to use pipe hole sleeve sold separately.





- Drill a hole with whole core drill.
- In case of rear piping draw out, cut off the lower and the right side portions of the sleeve collar.

Preparation of indoor unit

Mounting of connecting wires

- ① Remove the lid.
- ② Remove the terminal cover.
- ③ Remove the wiring clamp.
- ④ Connect the connecting wire securely to the terminal block.
 - 1) Connect the connection wire securely to the terminal block. If the wire is not affixed completely, contact will be poor, and it is dangerous as the terminal block may heat up and catch fire.
 - 2) Take care not to confuse the terminal numbers for indoor and outdoor connections.
- ⑤ Fix the connecting wire by wiring clamp.
- ⑥ Attach the terminal cover.
- ⑦ Attach the lid.

Relation between setting plate and indoor unit



CAUTION

In case of faulty wiring connection, the indoor unit stops, and then the run lamp turns on and the timer lamp blinks.

Use cables for interconnection wiring to avoid loosening of the wires. CENELEC code for cables Required field cables.

H05RN4G1.5 (Example) or 245/CE57

H Harmonized cable type

05 300/500 volts

R Natural and/or synch. rubber wire insulation

Stranded core

G Number of conductors


4 or 5 One conductor of the cable is the earth conductor (yellow/green)

1.5 Section of copper wire (mm²)


- Perform wiring, please take care of connecting the terminal number of outdoor unit terminal block.

Installing the support of piping

Piping is possible in the rear, left, left rear, left downward, right or downward direction.




- Matters of special notice when piping from left or central//rear of the unit.
[Top view]



Since this air conditioner has been designed to collect dew drops on the rear surface to the drain pan, do not attach the power cord above the gutter.



Shaping of pipings



- Hold the bottom of the piping and fix direction before stretching it and shaping it.
- Sufficient care must be taken not to damage the panel when connecting pipes.

Drainage

- Arrange the drain hose in a downward angle.
- Avoid the following drain piping.



The drain hose tip is in the gutter.


The gap to the ground is 5 cm or less.

CAUTION


- Go through all installation steps and check if the drainage is all right. Otherwise, water leak may occur.
- Insert the drain cap which was removed at procedure "2" securely using a hexagonal wrench etc.
- Be careful that If it is not inserted securely, water leakage may occur.

- Insert the drain hose located under the heat exchanger, and ensure that the water is discharged outdoor.
- Note: Be careful that if it is not inserted securely, water leakage may occur.


Fixing of indoor unit



Installation Steps



- How to remove the indoor unit from the installation board



INSTALLATION OF THE OUTDOOR UNIT

Fixing of outdoor


- Make sure that the unit is stable in installation.
Fix the unit to stable base.
- When installing the unit at a higher place or where it could be toppled by strong winds, secure the unit firmly with foundation bolts, wire, etc.

Electric wiring work

- Always perform grounding system installation work with the power cord unplugged.
- Connect a pair bearing a common terminal number with an indoor-outdoor connecting wire.
- In cabling, fasten cables securely with cable clamps so that no external force may work on terminal connections.
- Grounding terminals are provided in the control box.

⚠ CAUTION

Always use an earth leakage circuit breaker designed for inverter circuits
to prevent a faulty operation.



Drain piping work

- Execute drain piping by using a drain elbow and drain grommets supplied separately as accessories, where water drained from the outdoor unit is a problem.
- Water may drip where there is a larger amount of drain water. Seal around the drain elbow and drain grommets with putty or adequate caulking material.
- Condensed water may flow out from vicinity of operation valve or connected pipes.
- Where you are likely to have several days of sub-zero temperatures in a row, do not use a drain elbow and drain grommets. (There is a risk of drain water freezing inside and blocking the drain.)

⚠ CAUTION

- Do not put a grommet on this hole.**
This is a supplementary drain hole to discharge drain water, when a large quantity of it is gathered.

power cable, indoor - outdoor connecting wire circuit diagram

- Always perform grounding system installation work with the power cord unplugged.
- Connect a pair bearing a common terminal number with an indoor-outdoor connecting wire.
- In cabling, fasten cables securely with cable clamps so that no external force may work on terminal connections.
- Grounding terminals are provided in the control box.


- The specifications shown in the above table are for units without heaters. For units with heaters, refer to the installation instructions or the construction instructions of the indoor unit.
- Switchgear or Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
- The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.

Phase	Model	Earth leakage breaker	Switchgear or Circuit Breaker Over current protector rated capacity	Power source (minimum)	Interconnecting and grounding wires (minimum)
Single phase	SRK25 / DXXK09	15A, 30mA, 0.1sec or less	30A	16A	2.0mm ²
-phase	SRK35 / DXXK12				1.5mm ² X 4
	SRK45 / DXXK15				

CONNECTION OF REFRIGERANT PIPINGS

Preparation

Keep the openings of the pipes covered with tapes etc. to prevent dust, sand, etc. from entering them.



- Remove the flared nuts.
(on both liquid and gas sides)


- ⚠ CAUTION Do not apply refrigerating machine oil to the flared surface.

● Flaring WORK

Measurement B (mm)	Copper pipe diameter for R410A	Clutch type flare tool	Conventional (R22) flare tool	Wing nut type
Measurement B				
φ6.35	0.0~0.5	1.0~1.5	1.5~2.0	
φ9.52	0.0~0.5	1.0~1.5	1.5~2.0	
φ12.7	0.0~0.5	1.0~1.5	2.0~2.5	


⚠ CAUTION

- Do not apply excess torque to the flared nuts.**
Otherwise, the flared nuts may crack depending on the conditions and refrigerant leak may occur.



- Connect the pipes on both liquid and gas sides.



- Tighten the nuts to the following torque.
Liquid side (φ6.35) : 14.0 ~ 18.0 N·m (1.4 ~ 1.8 kgf·m)
Gas side (φ9.52) : 34.0 ~ 42.0 N·m (3.4 ~ 4.2 kgf·m)
(φ12.7) : 48.0 ~ 61.0 N·m (4.9 ~ 6.1 kgf·m)



- Tighten the nuts to the following torque.
Liquid side (φ6.35) : 14.0 ~ 18.0 N·m (1.4 ~ 1.8 kgf·m)
Gas side (φ9.52) : 34.0 ~ 42.0 N·m (3.4 ~ 4.2 kgf·m)
(φ12.7) : 48.0 ~ 61.0 N·m (4.9 ~ 6.1 kgf·m)

Air purge

- ① Tighten all flare nuts in the pipings both indoor and outside wall so as not to cause leak.
 - ② Connect operation valve, charge hose, manifold valve and vacuum pump as is illustrated right.
 - ③ Open manifold valve handle Lo to its full width, and perform vacuum or evacuation.
 - ④ Continue the vacuum or evacuation operation for 15 minutes or more and check to see that the vacuum gauge reads -0.1MPa.
 - ⑤ After completing vacuum operation, close the Lo handle and stop operation of the vacuum pump.
 - ⑥ After completing vacuum operation, fully open operation valve (Both gas and liquid sides) with hexagon headed wrench.
 - ⑦ Check for possible leakage of gas in the connection parts of both indoor and outdoor.
- Since the system uses check joints differing in diameter from those found on the conventional models, a charge hose (for R22) presently in use is not applicable. Please use one designed specifically for R410A.
- Please use an anti-reverse flow type vacuum pump adapter so as to prevent vacuum pump oil from running back into the system. Oil running back into an air-conditioning system may cause the refrigerant cycle to break down.

Insulation of the connection portion**INSTALLATION TEST CHECK POINTS**

Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the instruction manual.

After installation


- The power supply voltage is correct as the rating.
 - No gas leaks from the joints of the operation valve.
 - Power cables and crossover wires are securely fixed to the terminal board.
 - The screw of the lid is tightened securely.
 - The screw of the service panel is tightened securely.
 - Operation valve is fully open.
 - The pipe joints for indoor and outdoor pipes have been insulated.
- Operation of the unit has been explained to the customer.
- (Three-minute restart preventive timer)
When the air conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not a malfunction.

9. OUTLINE OF OPERATION CONTROL BY MICROCOMPUTER


(1) Operation control function by remote control

Remote control

◆ Operation section



Unit display section



(2) Unit ON/OFF button

When the remote control batteries become weak, or if the remote control is lost or malfunctioning, this button may be used to turn the unit on and off.


(a) Operation

Push the button once to place the unit in the automatic mode. Push it once more to turn the unit off.

(b) Details of operation

The unit will go into the automatic mode in which it automatically determines, from room temperature (as detected by sensor), whether to go into the cooling, thermal dry or heating modes.

Function Operation mode	Room temperature setting	Fan speed	Flap	Timer switch
COOL	About 24°C	Auto	Auto	Continuous
DRY	About 24°C			
HEAT	About 26°C			




(3) Auto restart function

(a) Auto restart function records the operational status of the air-conditioner immediately prior to be switched off by a power cut, and then automatically resumes operations after the power has been restored.

(b) The following settings will be cancelled:

- (i) Timer settings
- (ii) HIGH POWER operation

Notes (1) Auto restart function is set at on when the air-conditioner is shipped from the factory. Consult with your dealer if this function needs to be switched off.
(2) When power failure occurs, the timer setting is cancelled. Once power is resumed, reset the timer.
(3) If the jumper wire (J1) "AUTO RESTART" is cut, auto restart is disabled. (See the diagram at right)




(4) Custom cord switching procedure

If two wireless remote control are installed in one room, in order to prevent wrong operation due to mixed signals, please modify the printed circuit board in the indoor unit's control box and the remote control using the following procedure. Be sure to modify both boards. If only one board is modified, receiving (and operation) cannot be done.

(a) Modifying the indoor unit's printed circuit board


Take out the printed circuit board from the control box and cut off jumper wire (J2) using wire cutters.

After cutting of the jumper wire, take measures to prevent contact with the other the lead wires, etc.



(b) Modifying the wireless remote control

- (i) Remove the battery.
- (ii) Cut the jumper wire shown in the figure at right.



(5) High power operation

Pressing the HI POWER/ECONO button intensifies the operating power and initiates powerful cooling and heating operation for 15 minutes continuously. The remote control displays and the FAN SPEED display disappears.

- (a) During the HIGH POWER operation, the room temperature is not controlled. When it causes an excessive cooling and heating, press the HI POWER/ECONO button again to cancel the HIGH POWER operation.
- (b) HIGH POWER operation is not available during the DRY and the program timer operations.
- (c) When HIGH POWER operation is set after ON TIMER operation, HIGH POWER operation will start from the set time.
- (d) When the following operation are set, HIGH POWER operation will be canceled.
 - ① When the HI POWER/ECONO button is pressed again.
 - ② When the operation mode is changed.
 - ③ When it has been 15 minutes since HIGH POWER operation has started.
- (e) Not operable while the air conditioner is OFF.

(6) Economy operation

Pressing the HI POWER/ECONO button initiate a soft operation with the power suppressed in order to avoid an excessive cooling or heating. The unit operate 1.5°C higher than the setting temperature during cooling or 2.5°C lower than that during heating. The remote control displays ECONO mark and the FAN SPEED display disappears.

- (a) It will go into ECONOMY operation at the next time the air conditioner runs in the following cases.

- ① When the air-conditioner is stopped by ON/OFF button during ECONOMY operation.
- ② When the air-conditioner is stopped in SLEEP or OFF TIMER operation during ECONOMY operation.
- ③ When the operation is retrieved from CLEAN operation.

- (b) When the following operation are set, ECONOMY operation will be canceled.

- ① When the HI POWER/ECONO button is pressed again.
- ② When the operation mode is changed DRY to FAN.

- (c) Not operable while the air-conditioner is OFF.

- (d) The setting temperature is adjusted according to the following table.

Item	Mode	
	Cooling	Heating
Temperature adjustment	① +0.5	① -1.0
	② +1.0	② -2.0
	③ +1.5	③ -2.5


- ① at the start of operation.
- ② one hour after the start of operation.
- ③ two hours after the start of operation.

(7) Flap control

Control the flap by AIRFLOW (UP/DOWN) button on the wireless remote control.

(a) Flap

Each time when you press the AIRFLOW (UP/DOWN) button the mode changes as follows.




- Angle of flap from horizontal

Remote control display					
COOL , DRY	Approx. 15°	Approx. 25°	Approx. 35°	Approx. 45°	Approx. 59°
HEAT	Approx. 25°	Approx. 35°	Approx. 50°	Approx. 59°	Approx. 65°

(b) Swing

Flap moves in upward and downward directions continuously.

◆ In HEAT operation ◆ In COOL, DRY operation

**(c) Memory flap**

When you press the AIRFLOW (UP/DOWN) button once while the flap is operating, it stops swinging at an angle. Since this angle is memorized in the microcomputer, the flap will automatically be set at this angle when the next operation is started.

(d) When not operating

The flap returns to the position of air flow directly below, when operation has stopped.

(8) Timer operation**(a) Comfortable timer setting (ON timer)**

If the timer is set at ON when the operation select switch is set at the cooling or heating, or the cooling or heating in auto mode operation is selected, the comfortable timer starts and determines the starting time of next operation based on the initial value of 15 minutes and the relationship between the room temperature at the setting time (temperature of room temperature sensor) and the setting temperature.

(b) Sleep timer operation

Pressing the SLEEP button causes the temperature to be controlled with respect to the set temperature.

(c) OFF timer operation

The Off timer can be set at a specific time (in 10-minute units) within a 24-hour period.

(9) Outline of heating operation**(a) Operation of major functional components in heating mode**

	Heating			
	Thermostat ON	Thermostat OFF	Defrost	Failure
Compressor	ON	OFF	OFF	OFF
Indoor fan motor	ON	ON(HOT KEEP)	OFF	OFF
Outdoor fan motor	ON	OFF (few minutes ON)	OFF	OFF
4-way valve	ON	ON	OFF	OFF (3 minutes ON)

(b) Details of control at each operation mode (pattern)**(i) Fuzzy operation**

Deviation between the room temperature setting correction temperature and the suction air temperature is calculated in accordance with the fuzzy rule, and used for control of the air capacity and the compressor command speed.

Model	SRK25ZMP-SJ	SRK35ZMP-SJ
Fan speed		
AUTO	20~115rps	
HI	20~115rps	
MED	20~72rps	20~84rps
LO	20~54rps	20~62rps

When the defrosting, protection device, etc. is actuated, operation is performed in the corresponding mode.


(ii) Hot keep operation

If the hot keep operation is selected during the heating operation, the indoor blower is controlled based on the temperature of the indoor heat exchanger (Th2) to prevent blowing of cool wind.

However, if the fan speed setting is HI and room temperature is 19°C or higher, this control is not executed.

(c) Defrosting operation

- (i) Starting conditions (Defrosting operation can be started only when all of the following conditions are met.)
 - 1) After start of heating operation
When it elapsed 35 (model SRK35 : 45) minutes. (Accumulated compressor operation time)
 - 2) After end of defrosting operation
When it elapsed 35 (model SRK35 : 45) minutes. (Accumulated compressor operation time)
 - 3) Outdoor heat exchanger sensor (TH1) temperature
When the temperature has been below -5°C for 3 minutes continuously.
 - 4) The difference between the outdoor air sensor temperature and the outdoor heat exchanger sensor temperature
 - The outdoor air temperature $\geq 0^\circ\text{C}$: 7°C or higher
 - $-15^\circ\text{C} \leq$ The outdoor air temperature $< 0^\circ\text{C}$: $2/15 \times$ The outdoor air temperature + 7°C or higher
 - The outdoor air temperature $< -15^\circ\text{C}$: -5°C or higher


Models SRK25, 35ZMP-SJ

- 5) During continuous compressor operation

In addition, when the speed command from the indoor control of the indoor unit during heating operation has counted 0 rps 10 times or more and all conditions of 1), 2), 3) and 5) above and the outdoor air temperature is 3°C or less are satisfied (note that when the temperature for outdoor heat exchanger sensor (TH1) is -5°C or less: 62 rps or more, -4°C or less: less than 62 rps), defrost operation is started.

- (ii) Ending conditions (Operation returns to the heating cycle when either one of the following is met.)

- 1) Outdoor heat exchanger sensor (TH1) temperature: 13°C or higher
- 2) Continued operation time of defrosting → For more than 16 minutes and 50 seconds.



※Depends on an operation condition, the time can be longer than 7 minutes.

(10) Outline of cooling operation

(a) Operation of major functional components in Cooling mode

	Cooling		
	Thermostat ON	Thermostat OFF	Failure
Compressor	ON	OFF	OFF
Indoor fan motor	ON	ON	ON
Outdoor fan motor	ON	OFF (few minutes ON)	OFF (few minutes ON)
4-way valve	OFF	OFF	OFF

(b) Detail of control in each mode (Pattern)

(i) Fuzzy operation


During the fuzzy operation, the air flow and the compressor command speed are controlled by calculating the difference between the room temperature setting correction temperature and the suction air temperature.

Model \ Fan speed	SRK25ZMP-SJ	SRK35ZMP-SJ
AUTO	20~74rps	20~98rps
HI	20~74rps	20~98rps
MED	20~52rps	20~74rps
LO	20~38rps	20~46rps

(11) Outline of automatic operation

(a) Determination of operation mode

The unit checks the indoor air temperature and the outdoor air temperature, determines the operation mode, and then begins in the automatic operation.



- (b) The unit checks the temperature every hour after the start of operation and, if the result of check is not same as the previous operation mode, changes the operation mode.
 - (i) If the setting temperature is changed with the remote control, the operation mode is judged immediately.
 - (ii) When both the indoor and the outdoor air temperatures are in the range "A", cooling or heating is switched depending on the difference between the setting temperature and the indoor air temperature.
 - (iii) When the operation mode has been judged following the change of setting temperature with the remote control, the hourly judgment of operation mode is cancelled.
- (c) When the unit is started again within one hour after the stop of automatic operation or when the automatic operation is selected during heating, cooling or dehumidifying operation, the unit is operated in the previous operation mode.
- (d) Setting temperature can be adjusted within the following range. There is the relationship as shown below between the signals of the wireless remote control and the setting temperature.

		Signals of wireless remote control (Display)												
		-6	-5	-4	-3	-2	-1	±0	+1	+2	+3	+4	+5	+6
Setting temperature	Cooling	18	19	20	21	22	23	24	25	26	27	28	29	30
	Dehumidifying	19	20	21	22	23	24	25	26	27	28	29	30	31
	Heating	20	21	22	23	24	25	26	27	28	29	30	31	32

- (e) When the unit is operated automatically with the wired remote control connected, the cooling operation is controlled according to the display temperatures while the setting temperature is compensated by +1°C during dehumidifying or by +2°C during heating.

(12) Protection control function

(a) Dew prevention control [Cooling]:Prevents dewing on the indoor unit.

(i) Operating conditions: When the following conditions have been met for more than 30 minutes after starting operation


- 1) Compressor's command speed is 32 rps or higher.
- 2) Detected value of humidity is 68% or higher.

(ii) Contents of operation

- 1) Air capacity control

Item	Model	
	SRK25, 35ZMP-SJ	
LO	Upper limit of compressor's command speed	RangeA: 45rps, RangeB: 45rps
	Indoor fan	4th speed
AUTO,HI,MED	Upper limit of compressor's command speed	RangeA: 45rps, RangeB: 45rps
	Indoor fan	Adaptable to compressor's command speed (Lower limit 4th speed)

Note (1) Ranges A and B are as shown below.



- 2) When this control has continued for more than 30 minutes continuously, the following wind direction control is performed.
 - a) When the vertical wind direction is set at other than the vertical swing, the flaps change to the horizontal position.
 - b) When the horizontal wind direction is set at other than the horizontal swing, the louver changes to the vertical position.

(iii) Resetting condition: When any of followings is met

- 1) Compressor's command speed is less than 32 rps.
- 2) Detected value of humidity is less than 63%.


(b) Frost prevention control (During cooling or dehumidifying)

(i) Operating conditions

- 1) Indoor heat exchanger temperature (Th2) is lower than 5°C.
- 2) 5 minutes after reaching the compressor command speed except 0 rps.

(ii) Detail of anti-frost operation

Indoor heat exchanger temperature	5°C or lower	2.5°C or lower
Item		
Lower limit of compressor command speed	22 rps	0 rps
Indoor fan	Depends on operation mode	Protects the fan tap just before frost prevention control
Outdoor fan	Depends on command speed	Depends on stop mode
4-way valve	OFF	



Notes (1) When the indoor heat exchanger temperature is in the range of 2.5~5°C, the speed is reduced by 4 rps at each 20 seconds.
 (2) When the temperature is lower than 2.5°C, the compressor is stopped.
 (3) When the indoor heat exchanger temperature is in the range of 5~8°C, the compressor command speed is maintained.

(iii) Reset conditions: When either of the following condition is satisfied.

- 1) The indoor heat exchanger temperature (Th2) is 8°C or higher.
- 2) The compressor command speed is 0 rps.

(c) Cooling overload protective control

- (i) Operating conditions:** When the outdoor air temperature (TH2) has become continuously for 30 seconds at 41°C or more, or 47°C or more with the compressor running, the lower limit speed of compressor is brought up.

Item	Model	
	SRK25, 35ZMP-SJ	
Outdoor air temperature	41°C or more	47°C or more
Lower limit speed	30 rps	40 rps

(ii) Detail of operation

- 1) The outdoor fan is stepped up by 3 speed step. (Upper limit 8th speed.)
- 2) The lower limit of compressor command speed is set to 30 or 40 rps and even if the calculated result becomes lower than that after fuzzy calculation, the speed is kept to 30 or 40 rps. However, when the thermo OFF, the speed is reduced to 0 rps.

(iii) Reset conditions: When either of the following condition is satisfied.

- 1) The outdoor air temperature is lower than 40°C.
- 2) The compressor command speed is 0 rps.


(d) Cooling high pressure control

- (i) Purpose:** Prevents anomalous high pressure operation during cooling.

- (ii) Detector:** Outdoor heat exchanger sensor (TH1)

(iii) Detail of operation:

(Example) Fuzzy



Notes (1) When the outdoor heat exchanger temperature is in the range of B~C °C, the speed is reduced by 8 rps at each 20 seconds.

(2) When the temperature is C °C or higher, the compressor is stopped.

(3) When the outdoor heat exchanger temperature is in the range of A~B °C, if the compressor command speed is been maintained and the operation has continued for more than 20 seconds at the same speed, it returns to the normal cooling operation.

• Temperature list

	A	B	C
Outdoor air temperature $\geq 32^{\circ}\text{C}$	50	52	56
Outdoor air temperature $< 32^{\circ}\text{C}$	42	44	50

(e) Cooling low outdoor air temperature protective control


- (i) Operating conditions:** When the outdoor air temperature (TH2) is 22°C or lower continues for 20 seconds while the compressor command speed is other than 0 rps.

(ii) Detail of operation:

- 1) The lower limit of the compressor command speed is set to 50 <44> (30) rps and even if the speed becomes lower than 50 <44> (30) rps, the speed is kept to 50 <44> (30) rps. However, when the thermo OFF, the speed is reduced to 0 rps.
- 2) The upper limit of the compressor command speed is set to 50 <50> (60) rps and even if the calculated result becomes higher than that after fuzzy calculation, the speed is kept to 50 <50> (60) rps.

Notes (1) Values in < > are for outdoor air temperature is A°C or B°C

(2) Values in () are for outdoor air temperature is C°C or D°C



- Values of A, B, C, D, E, F

	Outdoor air temperature (°C)					
	E	F	A	B	C	D
First time	-8	-5	0	3	22	25
After the second times	-2	1	5	8	25	28

- (iii) **Reset conditions:** When either of the following condition is satisfied

- 1) The outdoor air temperature (TH2) is D °C or higher.
- 2) The compressor command speed is 0 rps.


(f) Heating high pressure control

- (i) **Purpose:** Prevents anomalous high pressure operation during heating.

- (ii) **Detector:** Indoor heat exchanger sensor (Th2)

- (iii) **Detail of operation:**

(Example) Fuzzy



- Notes
- (1) When the indoor heat exchanger temperature is in the range of B~C °C, the speed is reduced by 4 rps at each 10 seconds.
 - (2) When the indoor heat exchanger temperature is in the range of C~D °C, the speed is reduced by 8 rps at each 10 seconds. When the temperature is D °C or higher continues for 1 minute, the compressor is stopped.
 - (3) When the indoor heat exchanger temperature is in the range of A~B °C, if the compressor command speed is been maintained and the operation has continued for more than 10 seconds at the same speed, it returns to the normal heating operation.
 - (4) Indoor blower retains the fan tap when it enters in the high pressure control. Outdoor blower is operated in accordance with the speed.

● Temperature list

Models SRK25, 35

Unit : °C

	A	B	C	D
RPSmin < 50	48	52	54	55
50 ≤ RPSmin < 91	48.5	54.5	58	61
91 ≤ RPSmin < 97	48.5	54.5 ~ 51.5	58	61
97 ≤ RPSmin < 100	48.5	51.5 ~ 50	58 ~ 56	61
100 ≤ RPSmin < 115	48.5 ~ 40.1	50 ~ 42	56 ~ 47.3	61
115 ≤ RPSmin	40.1	42	47.3	61

Note (1) RPSmin: The lower one between the compressor command speed

(g) Heating overload protective control**(i) Indoor unit side**

1) Operating conditions : When the outdoor air temperature (TH2) is 17°C or higher continues for 30 seconds while the compressor command speed other than 0 rps.

2) Detail of operation : The indoor fan is stepped up by 1 speed step. (Upper limit 8th speed)

3) Reset conditions : The outdoor air temperature (TH2) is lower than 16°C.


(ii) Outdoor unit side

1) Operating conditions : When the outdoor air temperature (TH2) is 17 or 22 (14 or 20)°C or higher continues for 30 seconds while the compressor command speed other than 0 rps.

2) Detail of operation: Upper and lower limits of compressor speed and the outdoor unit fan speed are restricted.

Models SRK25, 35

	Compressor command speed (rps)		Outdoor fan speed
	Lower limit	Upper limit	
ON1	—	—	2nd speed
ON2	40	60	1st speed




3) Reset conditions: When the outdoor air temperature drops below 16°C.

(h) Heating low outdoor temperature protective control**(i) Protective control I**

1) Operating conditions: When the outdoor air temperature (TH2) is lower than 2°C or higher continues for 30 seconds while the compressor command speed is other than 0 rps.

2) Detail of operation: The lower limit compressor command speed is changed as shown in the figure below.



3) Reset conditions: When either of the following condition is satisfied.

a) The outdoor air temperature (TH2) becomes 4°C.

b) The compressor command speed is 0 rps.

(ii) Protective control II

1) Operating conditions: When the outdoor heat exchanger sensor (TH1) is -10°C or lower continuously for 10 minutes while the compressor command speed is other than 0 rps.

2) Detail of operation: Upper limit of compressor command speek is 115rps.

3) Reset conditions: When the either of the following condition is satisfied.

a) When the outdoor heat exchanger sensor (TH1) becomes -8°C or higher.

b) When the compressor command speed is 0 rps.


(i) Compressor overheat protection

(i) Purpose: It is designed to prevent deterioration of oil, burnout of motor coil and other trouble resulting from the compressor overheat.

(ii) Detail of operation

- 1) Speeds are controlled with temperature detected by the sensor mounted on the discharge pipe.

(Example) Fuzzy



Notes (1) When the discharge pipe temperature is in the range of 100 to 110 °C, the speed is reduced by 4 rps.

(2) When the discharge pipe temperature is raised and continues operation for 20 seconds without changing, then the speed is reduced again by 4 rps.

(3) If the discharge pipe temperature is in the range of 90~100°C even when the compressor command speed is maintained for 60 second when the temperature is in the range of 90~100°C, the speed is raised by 1 rps and kept at that speed for 60 second. This process is repeated until the command speed is reached.

(4) Lower limit speed

	Cooling	Heating
Models SRK25, 35	20 rps	30 rps

- 2) If the temperature of 110°C is detected by the sensor on the discharge pipe, then the compressor will stop immediately.

When the discharge pipe temperature drops and the time delay of 3 minutes is over, the unit starts again within 1 hour but there is no start at the third time.

(j) Current safe

(i) Purpose: Current is controlled not to exceed the upper limit of the setting operation current.

(ii) Detail of operation: Input current to the converter is monitored with the current sensor fixed on the printed circuit board of the outdoor unit and, if the operation current value reaches the limiting current value, the compressor command speed is reduced.

If the mechanism is actuated when the speed of compressor command is less than 30 rps, the compressor is stopped immediately. Operation starts again after a delay time of 3 minutes.

(k) Current cut

(i) Purpose: Inverter is protected from overcurrent.

(ii) Detail of operation: Output current from the converter is monitored with a shunt resistor and, if the current exceeds the setting value, the compressor is stopped immediately. Operation starts again after a delay time of 3 minutes.

(l) Outdoor unit failure

This is a function for determining when there is trouble with the outdoor unit during air conditioning.

The compressor is stopped if any one of the following in item (i), (ii) is satisfied. Once the unit is stopped by this function, it is not restarted.

- (i) When the input current is measured at 1 A or less for 3 continuous minutes or more.
- (ii) If the compressor command sends a 0 rps signal to the indoor unit 3 times or more within 20 minutes of the power being turned on.

(m) Indoor fan motor protection

When the air conditioner is operating and the indoor fan motor is turned ON, if the indoor fan motor has operated at 300 min^{-1} or under for more than 30 seconds, the unit enters first in the stop mode and then stops the entire system.

(n) Serial signal transmission error protection

(i) Purpose: Prevents malfunction resulting from error on the indoor ↔ outdoor signals.

(ii) Detail of operation: If the compressor is operating and a serial signal cannot be received from the indoor control with outdoor control having serial signals continues for 7 minute and 35 seconds, the compressor is stopped.

After the compressor has been stopped, it will be restarted after the compressor start delay if a serial signal can be received again from the indoor control.

(o) Rotor lock

If the motor for the compressor does not turn after it has been started, it is determined that a compressor lock has occurred and the compressor is stopped.

(p) Outdoor fan motor protection

If the outdoor fan motor has operated at 75 rpm or under for more than 30 seconds, the compressor and fan motor are stopped.

(q) Outdoor fan control at low outdoor temperature**(i) Cooling**

1) Operating conditions: When the outdoor air temperature (TH2) is 22°C or lower continues for 30 seconds while the compressor command speed is other than 0 rps.

2) Detail of operation: After the outdoor fan operates at A speed for 60 seconds; the corresponding outdoor heat exchanger temperature shall implement the following controls.

● Value of A

		Outdoor fan
Outdoor temperature > 10°C		2nd speed
Outdoor temperature ≤ 10°C		1st speed

a) Outdoor heat exchanger temperature (TH1) ≤ 21°C

After the outdoor fan speed drops (down) to 1 speed for 60 seconds; if the outdoor heat exchanger temperature is lower than 21°C, gradually reduce the outdoor fan speed by 1 speed. (Lower limit 1st speed)

b) 21°C < Outdoor heat exchanger temperature (TH1) ≤ 38°C

After the outdoor fan speed maintains at A speed for 20 seconds; if the outdoor heat exchanger temperature is 21°C~38°C, maintain outdoor fan speed.

c) Outdoor heat exchanger tempeature (TH1) > 38°C

After the outdoor fan speed rises (up) to 1 speed for 60 seconds; if the outdoor heat exchanger temperature is higher than 38°C, gradually increase outdoor fan speed by 1 speed. (Upper limit 3rd speed)

3) Reset conditions: When either of the following conditions is satisfied

a) The outdoor air temperature (TH2) is 25°C or higher.

b) The compressor command speed is 0 rps.

(ii) Heating

1) Operating conditions: When the outdoor air temperature (TH2) is 4°C or lower continues for 30 seconds while the compressor command speed is other than 0 rps.

2) Detail of operation: The outdoor fan is stepped up by 2 speed step at each 20 seconds. (Upper limit 8th speed)

3) Reset conditions: When either of the following conditions is satisfied

a) The outdoor air temperature (TH2) is 6°C or higher.

b) The compressor command speed is 0 rps.

(r) Refrigeration cycle system protection

(i) Starting conditions

- 1) When 5 minutes have elapsed after the compressor ON or the completion of the defrost control
- 2) Other than the defrost control
- 3) When, after meeting the conditions of 1) and 2) above, the compressor speed, indoor air temperature (Th1) and indoor heat exchanger temperature (Th2) have met the conditions in the following table for 10 minutes:

Operation mode	Compressor speed (N)	Indoor air temperature (Th1)	Indoor air temperature (Th1)/ Indoor heat exchanger temperature (Th2)
Cooling	50≤N	10≤Th1≤40	Th1-4<Th2
Heating(1)	50≤N	0≤Th1≤40	Th2<Th1+6

Note (1) Except that the fan speed is HI in heating operation.

(ii) Contents of control

- 1) When the conditions of (i) above are met, the compressor stops.
- 2) Error stop occurs when the compressor has stopped 3 times within 60 minutes.

(iii) Resetting condition

When the compressor has been turned OFF

(13) Outline of dry (dehumidifying) operation


(a) Purpose of DRY mode

The purpose is "Dehumidification", and not to control the humidity to the target condition.

Indoor/outdoor unit control the operation condition to reduce the humidity, and also prevent over cooling.

(b) Outline of control

(i) Indoor unit fan speed and compressor are controlled by the area which is selected by the temp. difference



(ii) The indoor unit check the current area by every 5 minutes, and operate by the next checking.

(c) Other

When the outside temp. and room temp. is low for cooling operation, indoor unit can not operate in cooling. In this case, the units operate in heating to rise the room temp., and after that start DRY operation.

10. MAINTENANCE DATA

(1) Cautions

- (a) If you are disassembling and checking an air conditioner, be sure to turn off the power before beginning. When working on indoor units, let the unit sit for about 1 minute after turning off the power before you begin work. When working on an outdoor unit, there may be an electrical charge applied to the main circuit (electrolytic condenser), so begin work only after discharging this electrical charge (to DC 10 V or lower).
- (b) When taking out printed circuit boards, be sure to do so without exerting force on the circuit boards or package components.
- (c) When disconnecting and connecting connectors, take hold of the connector housing and do not pull on the lead wires.

(2) Items to check before troubleshooting


- (a) Have you thoroughly investigated the details of the trouble which the customer is complaining about?
- (b) Is the air conditioner running? Is it displaying any self-diagnosis information?
- (c) Is a power supply with the correct voltage connected?
- (d) Are the control lines connecting the indoor and outdoor units wired correctly and connected securely?
- (e) Is the outdoor unit's service valve open?

(3) Troubleshooting procedure (If the air conditioner does not run at all)


If the air conditioner does not run at all, diagnose the trouble using the following troubleshooting procedure. If the air conditioner is running but breaks down, proceed to troubleshooting step (4).

Important When all the following conditions are met, we say that the air conditioner will not run at all.

- (a) The RUN light does not light up.
- (b) The flaps do not open.
- (c) The indoor unit fan motors do not run.
- (d) The self-diagnosis display does not function.



(4) Troubleshooting procedure (If the air conditioner runs)



Note (1) Even in cases where only intermittent stop data are generated, the air conditioning system is normal. However, if the same protective operation recurs repeatedly (3 or more times), it will lead to customer complaints. Judge the conditions in comparison with the contents of the complaints.

(5) Self-diagnosis table

When this air conditioner performs an emergency stop, the reason why the emergency stop occurred is displayed by the flashing of display lights. If the air conditioner is operated using the remote control 3 minutes or more after the emergency stop, the trouble display stops and the air conditioner resumes operation.⁽¹⁾

Indoor unit display section		Description of trouble	Cause	Display (flashing) condition
RUN light	TIMER light			
1 - time flash	ON	Indoor heat exchanger sensor error	<ul style="list-style-type: none"> • Broken heat exchanger sensor wire, poor connector connection • Indoor PCB is faulty 	When a heat exchanger sensor wire disconnection is detected while operation is stopped. (If a temperature of -28°C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)
2 - time flash	ON	Room temperature sensor error	<ul style="list-style-type: none"> • Broken room temperature sensor wire, poor connector connection • Indoor PCB is faulty 	When a room temperature sensor wire disconnection is detected while operation is stopped. (If a temperature of -45°C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)
5 - time flash	ON	Active filter voltage error	<ul style="list-style-type: none"> • Defective active filter 	When the wrong voltage connected for the power supply. When the outdoor PCB is faulty.
6 - time flash	ON	Indoor fan motor error	<ul style="list-style-type: none"> • Defective fan motor, poor connector connection 	When conditions for turning the indoor unit's fan motor on exist during air conditioner operation, an indoor unit fan motor speed of 300 min ⁻¹ or lower is measured for 30 seconds or longer. (The air conditioner stops.)
7 - time flash	ON	Refrigeration cycle system protective control	<ul style="list-style-type: none"> • Service valve is closed. • Refrigerant is insufficient 	When refrigeration cycle system protective control operates.
Keeps flashing	1 - time flash	Outdoor air temperature sensor error	<ul style="list-style-type: none"> • Broken outdoor air temp. sensor wire, poor connector connection • Outdoor PCB is faulty 	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C or higher is detected for within 20 seconds after power ON. (The compressor is stopped.)
Keeps flashing	2 - time flash	Outdoor heat exchanger sensor error	<ul style="list-style-type: none"> • Broken heat exchanger sensor wire, poor connector connection • Outdoor PCB is faulty 	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C or higher is detected for within 20 seconds after power ON. (The compressor is stopped.)
Keeps flashing	4 - time flash	Discharge pipe sensor error	<ul style="list-style-type: none"> • Broken discharge pipe sensor wire, poor connector connection • Outdoor PCB is faulty 	-25°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. (The compressor is stopped.)
ON	1 - time flash	Current cut	<ul style="list-style-type: none"> • Compressor locking, open phase on compressor output, shortcircuit on power transistor, closed service valve 	The inverter output current (compressor motor current) exceeds the set value during compressor start. (The air conditioner stops.)
ON	2 - time flash	Trouble of outdoor unit	<ul style="list-style-type: none"> • Broken compressor wire • Compressor blockage 	When there is an emergency stop caused by trouble in the outdoor unit, or the input current value is found to be lower than the set value. (The air conditioner stops.)
ON	3 - time flash	Current safe stop	<ul style="list-style-type: none"> • Overload operation • Overcharge • Compressor locking 	When the compressor command speed is lower than the set value and the current safe has operated. (The compressor is stopped.)
ON	4 - time flash	Power transistor error	<ul style="list-style-type: none"> • Broken power transistor 	When there is an emergency stop caused by trouble in the outdoor unit, or the input current value is found to be lower than the set value continuously for 3 minutes or longer. (The compressor is stopped.)
ON	5 - time flash	Over heat of compressor	<ul style="list-style-type: none"> • Gas shortage, defective discharge pipe sensor, closed service valve 	When the value of the discharge pipe sensor exceeds the set value. (The air conditioner stops.)
ON	6 - time flash	Error of signal transmission	<ul style="list-style-type: none"> • Defective power supply, Broken signal wire, defective indoor/outdoor PCB 	When there is no signal between the indoor PCB and outdoor PCB for 10 seconds or longer (when the power is turned on), or when there is no signal for 7 minute 35 seconds or longer (during operation) (The compressor is stopped.)
ON	7 - time flash	Outdoor fan motor error	<ul style="list-style-type: none"> • Defective fan motor, poor connector connection 	When the outdoor unit's fan motor sped continues for 30 seconds or longer at 75 rpm or lower. (3 times) (The air conditioner stops.)
ON	Keeps flashing	Cooling high pressure protection	<ul style="list-style-type: none"> • Overload operation, over charge • Broken outdoor heat exchange sensor wire • Service valve is closed. 	When the value of the outdoor heat exchanger sensor exceeds the set value.
2 - time flash	2 - time flash	Rotor lock	<ul style="list-style-type: none"> • Defective compressor • Open phase on compressor • Defective outdoor PCB 	If the compressor motor's magnetic pole positions cannot be correctly detected when the compressor starts. (The air conditioner stops.)

Notes (1)The air conditioner cannot be restarted using the remote control for 3 minutes after operation stops.


(6) Service mode (Trouble mode access function)

This air conditioner is capable of recording error displays and protective stops (service data) which have occurred in the past. If self-diagnosis displays cannot be confirmed, it is possible to get a grasp of the conditions at the time trouble occurred by checking these service data.

(a) Explanation of terms


Term	Explanation
Service mode	The service mode is the mode where service data are displayed by flashing of the display lights when the operations in item (b) below are performed with the indoor control.
Service data	These are the contents of error displays and protective stops which occurred in the past in the air conditioner system. Error display contents and protective stop data from past anomalous operations of the air conditioner system are saved in the indoor unit control's non-volatile memory (memory which is not erased when the power goes off). There are two types of data, self-diagnosis data and stop data, described below.
Self-diagnosis data	These are the data which display the reason why a stop occurred when an error display (self-diagnosis display) occurred in an indoor unit. Data are recorded for up to 5 previous occurrences. Data which are older than the 5th previous occurrence are erased. In addition, data on the temperature of each sensor (room temperature, indoor heat exchanger, outdoor heat exchanger, outdoor air temperature, discharge pipe), remote control information (operation switching, fan speed switching) are recorded when trouble occurs, so more detailed information can be checked.
Stop data	These are the data which display the reason by a stop occurred when the air conditioning system performed protective stops, etc. in the past. Even if stop data alone are generated, the system restarts automatically. (After executing the stop mode while the display is normal, the system restarts automatically.) Data for up to 10 previous occasions are stored. Data older than the 10th previous occasion are erased. (Important) In cases where transient stop data only are generated, the air conditioner system may still be normal. However, if the same protective stop occurs frequently (3 or more times), it could lead to customer complaints.

(b) Service mode display procedure



*3: To count the number of flashes in the service mode, count the number of flashes after the light lights up for 1.5 second initially (start signal). (The time that the light lights up for 1.5 second (start signal) is not counted in the number of flashes.)

- In the case of current cut (example: stop code "42")
The RUN light (10's digit) flashes 4 times and the TIMER light (1's digit) flashes 2 times.
 $4 \times 10 + 2 \times 1 = 42 \rightarrow$ From the table, read the instructions for error code 42, "current cut".



*4: When in the service mode, when the remote control settings (operation switching, fan speed switching, temperature setting) are set as shown in the following table and sent to the air conditioner unit, the unit switches to display of service data.

① Self-diagnosis data

What are Self- These are control data (reasons for stops, temperature at each sensor, remote control information) diagnosis Data? from the time when there were error displays (abnormal stops) in the indoor unit in the past.

Data from up to 5 previous occasions are stored in memory. Data older than the 5th previous occasion are erased. The temperature setting indicates how many occasions previous to the present setting the error display data are and the operation switching and fan speed switching data show the type of data.

Remote control setting		Contents of output data
Operation switching	Fan speed switching	
Cooling	MED	Displays the reason for stopping display in the past (error code).
	HI	Displays the room temperature sensor temperature at the time the error code was displayed in the past.
	AUTO	Displays the indoor heat exchanger sensor temperature at the time the error code was displayed in the past.
Heating	LO	Displays the remote control information at the time the error code was displayed in the past.
	MED	Displays the outdoor air temperature sensor temperature at the time the error code was displayed in the past.
	HI	Displays the outdoor heat exchanger sensor temperature at the time the error code was displayed in the past.
	AUTO	Displays the discharge pipe sensor temperature at the time the error code was displayed in the past.

Remote control setting	Indicates the number of occasions previous to the present the error display data are from.
Temperature setting	
21°C	1 time previous (previous time)
22°C	2 times previous
23°C	3 times previous
24°C	4 times previous
25°C	5 times previous

(Example)

Remote control setting			Displayed data
Operation switching	Fan speed switching	Temperature setting	
Cooling	MED	21°C	Displays the reason for the stop (error code) the previous time an error was displayed.
		22°C	Displays the reason for the stop (error code) 2 times previous when an error was displayed.
		23°C	Displays the reason for the stop (error code) 3 times previous when an error was displayed.
		24°C	Displays the reason for the stop (error code) 4 times previous when an error was displayed.
		25°C	Displays the reason for the stop (error code) 5 times previous when an error was displayed.

(2) Stop data


Remote control setting			Displayed data
Operation switching	Fan speed switching	Temperature setting	
Cooling	LO	21°C	Displays the reason for the stop (stop code) the previous time when the air conditioner was stopped by protective stop control.
		22°C	Displays the reason for the stop (stop code) 2 times previous when the air conditioner was stopped by protective stop control.
		23°C	Displays the reason for the stop (stop code) 3 times previous when the air conditioner was stopped by protective stop control.
		24°C	Displays the reason for the stop (stop code) 4 times previous when the air conditioner was stopped by protective stop control.
		25°C	Displays the reason for the stop (stop code) 5 times previous when the air conditioner was stopped by protective stop control.
		26°C	Displays the reason for the stop (stop code) 6 times previous when the air conditioner was stopped by protective stop control.
		27°C	Displays the reason for the stop (stop code) 7 times previous when the air conditioner was stopped by protective stop control.
		28°C	Displays the reason for the stop (stop code) 8 times previous when the air conditioner was stopped by protective stop control.
		29°C	Displays the reason for the stop (stop code) 9 times previous when the air conditioner was stopped by protective stop control.
		30°C	Displays the reason for the stop (stop code) 10 times previous when the air conditioner was stopped by protective stop control.

(c) Error code, stop code table (Assignment of error codes and stop codes is done in common for all models.)

Number of flashes when in service mode	Stop code or Error code	Error content	Cause	Occurrence conditions	Error display	Auto recovery
RUN light (10's digit)	TIMER light (1's digit)					
OFF	OFF	0	Normal	—	—	—
	5 - time flash	05	Can not receive signals for 35 seconds (if communications have recovered)	Power supply is faulty. Power supply cables and signal lines are improperly wired. Indoor or outdoor PCB are faulty.	When 35 seconds passes without communications signals from either the outdoor unit or the indoor unit being detected correctly.	○ —
3 - time flash	5 - time flash	35	Cooling high pressure control	Cooling overload operation. Outdoor unit fan speed drops. Outdoor heat exchanger sensor is short circuit.	When the outdoor heat exchanger sensor's value exceeds the set value.	○ (5 times) ○
	6 - time flash	36	Compressor overheat 110°C	Refrigerant is insufficient. Discharge pipe sensor is faulty. Service valve is closed.	When the discharge pipe sensor's value exceeds the set value.	○ (2 times) ○
	7 - time flash	37	Outdoor heat exchanger sensor is abnormal	Outdoor heat exchanger sensor wire is disconnected. Connector connections are poor. Outdoor PCB is faulty.	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C higher is detected for 5 seconds continuously within 20 seconds after power ON.	○ (3 times) ○
	8 - time flash	38	Outdoor air temperature sensor is abnormal	Outdoor air temperature sensor wire is disconnected. Connector connections are poor. Outdoor PCB is faulty.	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C higher is detected for 5 seconds continuously within 20 seconds after power ON.	○ (3 times) ○
	9 - time flash	39	Discharge pipe sensor is abnormal (anomalous stop)	Discharge pipe sensor wire is disconnected. Connector connections are poor. Outdoor PCB is faulty.	-25°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature.	○ (3 times) ○
4 - time flash	2 - time flash	42	Current cut	Compressor lock. Compressor wiring short circuit. Compressor output is open phase. Outdoor PCB is faulty. Service valve is closed. Electronic expansion valve is faulty. Compressor is faulty.	Compressor start fails 42 times in succession and the reason for the final failure is current cut.	○ (2 times) ○
	7 - time flash	47	Active filter voltage error	Defective active filter	When the wrong voltage connected for the power supply. When the outdoor PCB is faulty.	○ —
	8 - time flash	48	Outdoor unit's fan motor is abnormal	Outdoor fan motor is faulty. Connector connections are poor. Outdoor PCB is faulty.	When a fan speed of 75 rpm or lower continues for 30 seconds or longer.	○ (3 times) ○
5 - time flash	1 - time flash	51	Short circuit in the power transistor (high side) Current cut circuit breakdown	Outdoor PCB is faulty. Power transistor is damaged.	When it is judged that the power transistor was damaged at the time the compressor started.	○ —
	7 - time flash	57	Refrigeration cycle system protective control	Service valve is closed. Refrigerant is insufficient.	When refrigeration cycle system protective control operates.	○ (3 times) ○
	8 - time flash	58	Current safe	Refrigerant is overcharge. Compressor lock. Overload operation.	When there is a current safe stop during operation.	— ○
	9 - time flash	59	Compressor wiring is unconnection Voltage drop Low speed protective control	Compressor wiring is disconnected. Power transistor is damaged. Power supply construction is defective. Outdoor PCB is faulty. Compressor is faulty.	When the current is 1A or less at the time the compressor started. When the power supply voltage drops during operation. When the compressor command speed is lower than 32 rps for 60 minutes.	○ ○
6 - time flash	OFF	60	Rotor lock	Compressor is faulty. Compressor output is open phase. Electronic expansion valve is faulty. Overload operation. Outdoor PCB is faulty.	After the compressor starts, when the compressor stops due to rotor lock.	○ (2 times) ○
	1 - time flash	61	Connection lines between the indoor and outdoor units are faulty	Connection lines are faulty. Indoor or outdoor PCB are faulty.	When 10 seconds passes after the power is turned on without communications signals from the indoor or outdoor unit being detected correctly.	○ —
	2 - time flash	62	Serial transmission error	Indoor or outdoor PCB are faulty. Noise is causing faulty operation.	When 7 minute 35 seconds passes without communications signals from either the outdoor unit or the indoor unit being detected correctly.	○ —
8 - time flash	OFF	80	Indoor unit's fan motor is abnormal	Indoor fan motor is faulty. Connector connections are poor. Indoor PCB is faulty.	When the indoor unit's fan motor is detected to be running at 300 rpm or lower speed with the fan motor in the ON condition while the air conditioner is running.	○ —
	2 - time flash	82	Indoor heat exchanger sensor is abnormal (anomalous stop)	Indoor heat exchanger sensor wire is disconnected. Connector connections are poor.	When a temperature of -28°C or lower is sensed continuously for 40 minutes during heating operation. (the compressor stops).	○ —
	4 - time flash	84	Anti-condensation control	High humidity condition. Humidity sensor is faulty.	Anti-condensation prevention control is operating.	— ○
	5 - time flash	85	Anti-frost control	Indoor unit fan speed drops. Indoor heat exchanger sensor is broken wire.	When the anti-frost control operates and the compressor stops during cooling operation.	— ○
	6 - time flash	86	Heating high pressure control	Heating overload operation. Indoor unit fan speed drops. Indoor heat exchanger sensor is short circuit.	When high pressure control operates during heating operation and the compressor stops.	— ○

Note (1) The number of flashes when in the Service Mode do not include the 1.5 second period when the lights light up at first (start signal). (See the example shown below.)

- In the case of current cut (example: stop code "42")
The RUN light (10's digit) flashes 4 times and the TIMER light (1's digit) flashes 2 times.
 $4 \times 10 + 2 \times 1 = 42 \rightarrow$ From the table, read the instructions for error code 42, "Current cut".



- (2) Abnormal Stop:
 — Is not displayed. (automatic recovery only)
 Displayed.
 If there is a () displayed, the error display shows the number of times that an automatic recovery occurred for the same reason has reached the number of times in ().
 If no () is displayed, the error display shows that the trouble has occurred once.
- (3) Automatic Recovery:
 — Does not occur
 Automatic recovery occurs.

(d) Remote control information tables

1) Operation switching

Display pattern when in service mode	Operation switching when there is an abnormal stop
RUN light (Operation switching)	
0	AUTO
1	DRY
2	COOL
3	FAN
4	HEAT


2) Fan speed switching

Display pattern when in service mode	Fan speed switching when there is an abnormal stop
TIMER light (Fan speed switching)	
0	AUTO
2	HI
3	MED
4	LO
6	HI POWER
7	ECONO

* If no data are recorded (error code is normal), the information display in the remote control becomes as follows.

Remote control setting	Display when error code is normal.
Operation switching	AUTO
Fan speed switching	AUTO

(Example): Operation switching, fan speed switching, cooling HI




(e) Room temperature sensor temperature, indoor heat exchanger sensor temperature, outdoor air temperature sensor temperature, outdoor heat exchanger sensor temperature table

		Units: °C											
		RUN light (10's digit)		0	1	2	3	4	5	6	7	8	9
Buzzer sound				6	-60	-61	-62	-63	-64				
Yes (sounds for 0.1 second)	6	-60	-61	-62	-63	-64							
	5	-50	-51	-52	-53	-54	-55	-56	-57	-58	-59		
	4	-40	-41	-42	-43	-44	-45	-46	-47	-48	-49		
	3	-30	-31	-32	-33	-34	-35	-36	-37	-38	-39		
	2	-20	-21	-22	-23	-24	-25	-26	-27	-28	-29		
	1	-10	-11	-12	-13	-14	-15	-16	-17	-18	-19		
	0		-1	-2	-3	-4	-5	-6	-7	-8	-9		
No (does not sound)	0	0	1	2	3	4	5	6	7	8	9		
	1	10	11	12	13	14	15	16	17	18	19		
	2	20	21	22	23	24	25	26	27	28	29		
	3	30	31	32	33	34	35	36	37	38	39		
	4	40	41	42	43	44	45	46	47	48	49		
	5	50	51	52	53	54	55	56	57	58	59		
	6	60	61	62	63	64	65	66	67	68	69		
	7	70	71	72	73	74	75	76	77	78	79		
	8	80	81	82	83	84	85	86	87	88	89		
	9	90	91	92	93	94	95	96	97	98	99		

* If no data are recorded (error code is normal), the display for each sensor becomes as shown below.

Sensor name	Sensor value displayed when the error code is normal
Room temperature sensor temperature	-19°C
Indoor heat exchanger sensor temperature	-64°C
Outdoor air temperature sensor temperature	-64°C
Outdoor heat exchanger sensor temperature	-64°C

(Example) Room temperature, indoor heat exchanger, outdoor air temperature, outdoor heat exchanger: “-9°C”



(f) Discharge pipe temperature table


		Units: °C									
		TIMER light (1's digit)									
		0	1	2	3	4	5	6	7	8	9
Buzzer sound		3	-60	-62	-64						
Yes (sounds for 0.1 second)	2		-40	-42	-44	-46	-48	-50	-52	-54	-56
	1		-20	-22	-24	-26	-28	-30	-32	-34	-36
	0			-2	-4	-6	-8	-10	-12	-14	-16
					-18						
No (does not sound)	0		0	2	4	6	8	10	12	14	16
	1		20	22	24	26	28	30	32	34	36
	2		40	42	44	46	48	50	52	54	56
	3		60	62	64	66	68	70	72	74	76
	4		80	82	84	86	88	90	92	94	96
	5		100	102	104	106	108	110	112	114	116
	6		120	122	124	126	128	130	132	134	136
	7		140	142	144	146	148	150			

* If no data is recorded (error code is normal), the display for sensor becomes as shown below.

Sensor name	Sensor value displayed when the error code is normal
Discharge pipe sensor temperature	-64°C

(Example) Discharge pipe temperature: “122°C”

* In the case of discharge pipe data, multiply the reading value by 2. (Below, $61 \times 2 = “122°C”$)




Service data record form


Customer				Model			
Date of investigation							
Machine name							
Content of complaint							
Remote control settings			Content of displayed data	Display results		Display content	
Temperature setting	Operation switching	Fan speed switching		Buzzer (Yes/No)	RUN light (Times)		
21	Cooling	MED	Error code on previous occasion.	/	/		
		HI	Room temperature sensor temperature on previous occasion.	/	/		
		AUTO	Indoor heat exchanger sensor temperature on previous occasion.	/	/		
	Heating	LO	Remote control information on previous occasion.	/	/		
		MED	Outdoor air temperature sensor temperature on previous occasion.	/	/		
		HI	Outdoor heat exchanger sensor temperature on previous occasion.	/	/		
22	Cooling	MED	Error code on second previous occasion.	/	/		
		HI	Room temperature sensor temperature on second previous occasion.	/	/		
		AUTO	Indoor heat exchanger sensor temperature on second previous occasion.	/	/		
	Heating	LO	Remote control information on second previous occasion.	/	/		
		MED	Outdoor air temperature sensor temperature on second previous occasion.	/	/		
		HI	Outdoor heat exchanger sensor temperature on second previous occasion.	/	/		
23	Cooling	MED	Error code on third previous occasion.	/	/		
		HI	Room temperature sensor temperature on third previous occasion.	/	/		
		AUTO	Indoor heat exchanger sensor temperature on third previous occasion.	/	/		
	Heating	LO	Remote control information on third previous occasion.	/	/		
		MED	Outdoor air temperature sensor temperature on third previous occasion.	/	/		
		HI	Outdoor heat exchanger sensor temperature on third previous occasion.	/	/		
24	Cooling	MED	Error code on fourth previous occasion.	/	/		
		HI	Room temperature sensor temperature on fourth previous occasion.	/	/		
		AUTO	Indoor heat exchanger sensor temperature on fourth previous occasion.	/	/		
	Heating	LO	Remote control information on fourth previous occasion.	/	/		
		MED	Outdoor air temperature sensor temperature on fourth previous occasion.	/	/		
		HI	Outdoor heat exchanger sensor temperature on fourth previous occasion.	/	/		
25	Cooling	MED	Error code on fifth previous occasion.	/	/		
		HI	Room temperature sensor temperature on fifth previous occasion.	/	/		
		AUTO	Indoor heat exchanger sensor temperature on fifth previous occasion.	/	/		
	Heating	LO	Remote control information on fifth previous occasion.	/	/		
		MED	Outdoor air temperature sensor temperature on fifth previous occasion.	/	/		
		HI	Outdoor heat exchanger sensor temperature on fifth previous occasion.	/	/		
21	Cooling	LO	Stop code on previous occasion.	/	/		
22		Stop code on second previous occasion.	/	/			
23		Stop code on third previous occasion.	/	/			
24		Stop code on fourth previous occasion.	/	/			
25		Stop code on fifth previous occasion.	/	/			
26		Stop code on sixth previous occasion.	/	/			
27		Stop code on seventh previous occasion.	/	/			
28		Stop code on eighth previous occasion.	/	/			
29		Stop code on ninth previous occasion.	/	/			
30		Stop code on tenth previous occasion.	/	/			
Judgment						Examiner	
Remarks							

(7) Inspection procedures corresponding to detail of trouble


Sensor error

[Broken sensor wire,
connector poor connection]

◆ Discharge pipe sensor temperature characteristics




◆ Sensor temperature characteristics (Room temp., indoor heat exchanger temp., outdoor heat exchanger temp., outdoor air temp.)



Indoor fan motor error

[Defective fan motor, connector poor connection, defective indoor PCB]




Notes (1) See page 53 for the fan motor and indoor PCB check procedure.


(2) After making sure the fan motor and indoor PCB are normal, connect the connectors and confirm that the fan motor is turning.
(If power is turned on while one or the other is broken down, it could cause the other to break down also.)

Current cut

[Compressor lock, Compressor wiring short circuit, Compressor output is open phase,
Outdoor PCB is faulty, Service valve is closed, EEV is faulty, Compressor faulty.]


**Current safe stop**

[Overload operation, compressor lock, overcharge]




Over heat of compressor

[Gas shortage, defective discharge pipe sensor]


**Error of signal transmission**

[Wiring error including power cable, defective indoor/outdoor PCB]



Trouble of outdoor unit

[Insufficient refrigerant amount, Faulty power transistor, Broken compressor wire]
 [Service valve close, Defective EEV, Defective outdoor PCB]



Proper power supply voltages are as follows.
 (At the power supply outlet)
 AC 220V : AC 198~242V
 AC 230V : AC 207~253V
 AC 240V : AC 216~264V

◆ Judgment of refrigerant quantity

- (1) Phenomenon of insufficient refrigerant
 - (a) Loss of capacity
 - (b) Poor defrosting
 (Frost is not removed completely.)
 - (c) Longer time of hot keep
 (5 minute or more)
 - (Normal time: Approx. 1 – 1 minute and 30 seconds)


Notes (1) For inspection of electronic expansion valve, see page 56

(2) For the output voltage check of power transistor, see page 54

(3) Check coil wire resistance, see page 49.

Outdoor fan motor error

[Defective fan motor, connector poor connection, defective outdoor PCB]




Notes (1) See page 56 for the fan motor and outdoor PCB check procedure.

- (2) After making sure the fan motor and outdoor PCB are normal, connect the connectors and confirm that the fan motor is turning.
 (If power is turned on while one or the other is broken down, it could cause the other to break down also.)

Rotor lock

[Defective compressor, defective outdoor PCB]



(8) Phenomenon observed after shortcircuit, wire breakage on sensor


(a) Indoor unit

Sensor	Operation mode	Phenomenon	
		Shortcircuit	Disconnected wire
Room temperature sensor	Cooling	Release of continuous compressor operation command.	Continuous compressor operation command is not released.
	Heating	Continuous compressor operation command is not released.	Release of continuous compressor operation command.
Heat exchanger sensor	Cooling	System can be operated normally.	Continuous compressor operation command is not released. (Anti-frosting)
	Heating	High pressure control mode (Compressor stop command)	Hot keep (Indoor fan stop)
Humidity sensor	Cooling	Refer to the table below.	Refer to the table below.
	Heating	Normal system operation is possible.	

■ Humidity sensor operation

Failure mode	Control input circuit reading	Air conditioning system operation
Disconnected wire	① Disconnected wire ② Disconnected wire ①② Disconnected wire	Humidity reading is 0% Anti-condensation control is not done.
Short Circuit	① and ② are short circuited	Humidity reading is 100% Anti-condensation control keep doing.

Remark: Do not perform a continuity check of the humidity sensor with a tester. If DC current is applied, it could damage the sensor.




(b) Outdoor unit

Sensor	Operation mode	Phenomenon	
		Shortcircuit	Disconnected wire
Heat exchanger sensor	Cooling	System can be operated normally.	Compressor stop.
	Heating	Defrosting is not performed.	Defrosting is performed for 10 minutes at approx. 35 (model SRK35:45) minutes.
Outdoor air temperature sensor	Cooling	System can be operated normally.	Compressor stop.
	Heating	Defrosting is not operated.	Defrosting is performed for 10 minutes at approx. 35 (model SRK35:45) minutes.
Discharge pipe sensor	All modes	Compressor overload protection is disabled. (Can be operated.)	Compressor stop

(9) Checking the indoor electrical equipment

(a) Indoor PCB check procedure




(b) Indoor unit fan motor check procedure

This is a diagnostic procedure for determining if the indoor unit's fan motor or the indoor PCB is broken down.

1) Indoor PCB output check

- Turn off the power.
- Remove the front panel, then disconnect the fan motor lead wire connector.
- Turn on the power. If the unit operates when the ON/OFF button is pressed, if trouble is detected after the voltages in the following figure are output for approximately 30 seconds, it means that the indoor PCB is normal and the fan motor is broken down.

If the voltages in the following figure are not output at connector pins No. ①, ④ and ⑤, the indoor PCB has failed and the fan motor is normal.



Measuring point	Resistance when normal
① - ③	DC 308~336V
④ - ③	DC 15V
⑤ - ③	DC several V (4~6V)
⑥ - ③	DC several V (4~6V)

2) Fan motor resistance check

Measuring point	Resistance when normal
① - ③ (Red - Black)	20 MΩ or higher
④ - ③ (White - Black)	20 kΩ or higher

Notes
 (1) Remove the fan motor and measure it without power connected to it.
 (2) If the measured value is below the value when the motor is normal, it means that the fan motor is faulty.

(C) Power transistor inspection procedure



[Use a tester with a needle indicator for the inspection. (Do not use a digital tester. Check in the AC 300 volt range.)]

(1) If there is a self-diagnosis display, inspect the compressor system (burns, wiring mistakes, etc.) If no problems are found, check the output of the power transistor.

(2) Output inspection procedure

Disconnect the terminals for the compressor.

If an output such as the one shown in the figure on the below can be measured, the power transistor and the circuit board for the outdoor unit are normal.

**(10) How to make sure of wireless remote control**

(11) Outdoor unit inspection points


Models SRK25ZMP-SJ, 35ZMP-SJ

◆ Check point of outdoor unit

⚠ CAUTION - HIGH VOLTAGE

High voltage is produced in the control box. Don't touch electrical parts in the control box for 5 minutes after the unit is stopped.


Color symbol	
Mark	Color
BK	Black
OR	Orange
RD	Red
WH	White
Y	Yellow
Y/G	Yellow/Green



(a) Inspection of electronic expansion valve

Electronic expansion valve operates for approx. 10 seconds after the power on, in order to determine its aperture. Check the operating sound and voltage during the period of time. (Voltage cannot be checked during operation in which only the aperture change occurs.)

- (i) If it is heard the sound of operating electronic expansion valve, it is almost normal.
- (ii) If the operating sound is not heard, check the output voltage.



- (iii) If voltage is detected, the outdoor PCB is normal.
- (iv) If the expansion valve does not operate (no operating sound) while voltage is detected, the expansion valve is defective.

• Inspection of electronic expansion valve as a separate unit

Measure the resistance between terminals with an analog tester.

Measuring point	Resistance when normal
1-6	
1-4	46 ± 4Ω
1-3	(at 20°C)
1-5	


(b) Outdoor unit fan motor check procedure

- When the outdoor unit fan motor error is detected, diagnose which of the outdoor unit fan motor or outdoor PCB is defective.
- Diagnose this only after confirming that the indoor unit is normal.

(i) Outdoor PCB output check

- 1) Turn off the power.
- 2) Disconnect the outdoor unit fan motor connector CNFAN.
- 3) When the indoor unit is operated by inserting the power supply plug and pressing (ON) the backup switch for more than 5 seconds, if the voltage of pin No. ② in the following figure is output for 30 seconds at 20 seconds after turning "ON" the backup switch, the outdoor PCB is normal but the fan motor is defective.
If the voltage is not detected, the outdoor PCB is defective but the fan motor is normal.

Note (1) The voltage is output 3 times repeatedly. If it is not detected, the indoor unit displays the error message.



(ii) Fan motor resistance check

Measuring point	Resistance when normal
⑥ - ④ (Red - Black)	20 MΩ or higher
③ - ④ (White - Black)	20 kΩ or higher

Notes (1) Remove the fan motor and measure it without power connected to it.

(2) If the measured value is below the value when the motor is normal, it means that the fan motor is faulty.

INVERTER WALL MOUNTED TYPE RESIDENTIAL AIR-CONDITIONERS



MITSUBISHI HEAVY INDUSTRIES, LTD.

Air-Conditioning & Refrigeration Systems

16-5, Konan 2-chome, Minato-ku, Tokyo, 108-8215 Japan

<http://www.mhi.co.jp>

Because of our policy of continuous improvement, we reserve the right to make changes in all specifications without notice.

© Copyright MITSUBISHI HEAVY INDUSTRIES, LTD.